

# REACTOR™

309574 rev.J

## Electric, Heated, Plural Component Proportioner


*For spraying polyurethane foam and polyurea coatings.*  
**Not for use in explosive atmospheres.**



**Important Safety Instructions:**

Read all warnings and instructions in this manual. Save these instructions.

See page 2 for **Table of Contents** and page 3 for **List of Models**.



T13764a-1

**PROVEN QUALITY. LEADING TECHNOLOGY.**

# Contents

<b>Models</b> .....	<b>3</b>	<b>Troubleshooting</b> .....	<b>16</b>
<b>Manual Conventions</b> .....	<b>4</b>	<b>Repair</b> .....	<b>20</b>
<b>Supplied Manuals</b> .....	<b>4</b>	Pump Removal .....	20
<b>Related Manuals</b> .....	<b>5</b>	Pump Installation .....	22
<b>Warning</b> .....	<b>6</b>	Drive Housing .....	24
<b>Before Beginning Repair</b> .....	<b>8</b>	Motor Brushes .....	26
<b>Flushing</b> .....	<b>8</b>	Circuit Breaker Module .....	28
<b>Pressure Relief Procedure</b> .....	<b>9</b>	Electric Motor .....	29
<b>Temperature Control Diagnostic Codes</b> .....	<b>10</b>	Motor Control Board .....	30
E01: High fluid temperature .....	10	Transducers .....	32
E02: High hose current .....	10	Temperature Control Board .....	34
E03: No hose current .....	11	Heater .....	36
E04: FTS or thermocouple not connected .....	11	Heated Hose .....	39
E05: Board overtemperature .....	11	Fluid Temperature Sensor (FTS) .....	40
<b>Motor Control Diagnostic Codes</b> .....	<b>12</b>	Display Module .....	46
Alarms .....	12	<b>Parts</b> .....	<b>49</b>
Warnings .....	12	248669 Conversion Kit .....	68
E21: No component A transducer .....	13	<b>Technical Data</b> .....	<b>69</b>
E22: No component B transducer .....	13	<b>Graco Standard Warranty</b> .....	<b>70</b>
E23: High pressure .....	13	<b>Graco Information</b> .....	<b>70</b>
E24: Pressure imbalance .....	13		
E25: High line voltage .....	14		
E26: Low line voltage .....	14		
E27: High motor temperature .....	14		
E28: High current in motor .....	14		
E29: Brush wear .....	14		

# Models

## E SERIES

Part No., Series	Model	Voltage (phase)	Full Load Peak Amps*	System Watts**	Heater Watts	Flow lb/min (kg/min)	Output per Cycle (A + B) gal. (liter)	Maximum Fluid Working Pressure psi (MPa, bar)
246025, D	E-20	230V (1)	48	11,100	6,000	20 (9)	.0104 (.0395)	2000 (14, 140)
246026, C	E-30	230V (1)	78	17,900	10,200	30 (13.5)	.0272 (0.1034)	2000 (14, 140)
246030, D	E-20	380V (3)	24	11,100	6,000	20 (9)	.0104 (.0395)	2000 (14, 140)
246031, C	E-30	380V (3)	34	17,900	10,200	30 (13.5)	.0272 (0.1034)	2000 (14, 140)
246034, D	E-20	230V (3)	32	11,100	6,000	20 (9)	.0104 (.0395)	2000 (14, 140)
246035, C	E-30	230V (3)	50	17,900	10,200	30 (13.5)	.0272 (0.1034)	2000 (14, 140)
248657, A	E-30 with 15.3kW	230V (1)	100	23,000	15,300	30 (13.5)	.0272 (0.1034)	2000 (14, 140)
248658, A	E-30 with 15.3kW	230V (3)	62	23,000	15,300	30 (13.5)	.0272 (0.1034)	2000 (14, 140)
248659, A	E-30 with 15.3kW	380V (3)	35	23,000	15,300	30 (13.5)	.0272 (0.1034)	2000 (14, 140)

## E-XP SERIES

Part No., Series	Model	Voltage (phase)	Full Load Peak Amps*	System Watts**	Heater Watts	Flow gpm (lpm)	Output per Cycle (A + B) gal. (liter)	Maximum Fluid Working Pressure psi (MPa, bar)
246024, C	E-XP1	230V (1)	69	15,800	10,200	1 (3.8)	.0104 (.0395)	2500 (17.2, 172)
246028, C	E-XP2	230V (1)	100	23,000	15,300	2 (7.6)	.0203 (.0771)	3500 (24.1, 241)
246029, C	E-XP1	380V (3)	24	15,800	10,200	1 (3.8)	.0104 (.0395)	2500 (17.2, 172)
246032, C	E-XP2	380V (3)	35	23,000	15,300	2 (7.6)	.0203 (.0771)	3500 (24.1, 241)
246033, C	E-XP1	230V (3)	43	15,800	10,200	1 (3.8)	.0104 (.0395)	2500 (17.2, 172)
246036, C	E-XP2	230V (3)	62	23,000	15,300	2 (7.6)	.0203 (.0771)	3500 (24.1, 241)

\* Full load amps with all devices operating at maximum capabilities. Fuse requirements at various flow rates and mix chamber sizes may be less.

\*\* E-20 and E-XP1 with 210 ft (64.1 m) hose; E-30 and E-XP2 with 310 ft (94.6 m) hose.

# Manual Conventions

## Warning

WARNING

A warning alerts you to possible serious injury or death if you do not follow instructions.

Symbols, such as fluid injection (shown), alert you to a specific hazard and direct you to read the indicated hazard warnings on pages 6-7.

## Caution

CAUTION

A caution alerts you to possible equipment damage or destruction if you do not follow instructions.

## Note

A note indicates additional helpful information.

# Supplied Manuals

The following manuals are shipped with the Reactor™ Proportioner. Refer to these manuals for detailed equipment information.

Order Part No. 15B535 for a compact disk of Reactor manuals translated in several languages.

Reactor Electric Proportioner	
Part No.	Description
309551	Reactor Electric Proportioner, Operation Manual (English)
309577	Displacement Pump, Repair-Parts Manual (English)
Reactor Electrical Diagrams (one of the following is included)	
Part No.	Description
309726	Electrical Diagrams, E-XP1 and E-20, 230V, 1 phase
309727	Electrical Diagrams, E-XP2 and E-30, 230V, 1 phase
309728	Electrical Diagrams, E-XP1 and E-20, 380V, 3 phase
309729	Electrical Diagrams, E-XP2 and E-30, 380V, 3 phase
309730	Electrical Diagrams, E-XP1 and E-20, 230V, 3 phase
309731	Electrical Diagrams, E-XP2 and E-30, 230V, 3 phase

# Related Manuals

The following manuals are for accessories used with the Reactor™.

Order Part No. 15B381 for a compact disk of Fusion manual translated in several languages.

Order Part No. 15B535 for a compact disk of Reactor manuals translated in several languages.

<b>Feed Pump Kits</b>	
<b>Part No.</b>	<b>Description</b>
309815	Instruction-Parts Manual (English)
<b>Air Supply Kit</b>	
<b>Part No.</b>	<b>Description</b>
309827	Instruction-Parts Manual (English) for Feed Pump Air Supply Kit
<b>Circulation and Return Tube Kits</b>	
<b>Part No.</b>	<b>Description</b>
309852	Instruction-Parts Manual (English)
<b>Heated Hose</b>	
<b>Part No.</b>	<b>Description</b>
309572	Instruction-Parts Manual (English)
<b>Fusion Air Purge Spray Gun</b>	
<b>Part No.</b>	<b>Description</b>
309550	Instruction-Parts Manual (English)
<b>Fusion Mechanical Purge Spray Gun</b>	
<b>Part No.</b>	<b>Description</b>
309856	Instruction-Parts Manual (English)
<b>Circulation Kit</b>	
<b>Part No.</b>	<b>Description</b>
309818	Instruction-Parts Manual (English)
<b>Data Reporting Kit</b>	
<b>Part No.</b>	<b>Description</b>
309867	Instruction-Parts Manual (English)
<b>Pump Wet-Cup Flush Kits and Reservoir Kit</b>	
<b>Part No.</b>	<b>Description</b>
309911	Instruction-Parts Manual (English)
<b>Transformer Repair Kit</b>	
<b>Part No.</b>	<b>Description</b>
309930	Instruction-Parts Manual (English)
<b>Rupture Disk Assembly Kit</b>	
<b>Part No.</b>	<b>Description</b>
309969	Instruction-Parts Manual (English)


**WARNING**
**SKIN INJECTION HAZARD**

High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. **Get immediate surgical treatment.**








- Do not point the gun at anyone or at any part of the body.
- Do not put your hand or fingers over the gun fluid nozzle.
- Do not stop or deflect leaks with your hand, body, glove, or rag.
- Do not “blow back” fluid; this is not an air spray system.
- Follow **Technical Data**, page 69, when you stop spraying and before cleaning, checking, or servicing equipment.
- Use lowest possible pressure when flushing, priming, or troubleshooting.
- Engage spray gun piston safety lock when not spraying.
- Tighten all fluid connections before operating the equipment.
- Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately. High pressure hose cannot be recoupled; replace the entire hose.

**FIRE, EXPLOSION, AND ELECTRIC SHOCK HAZARD**

Solvent and fumes in work area can ignite or explode. High voltage components can cause electric shock. To help prevent fire, explosion, and electric shock:




- Shut off main power switch and wait 5 minutes before opening Reactor cabinet door.
- All electrical wiring must be done by trained and qualified personnel and comply with all local codes.
- Ground equipment and conductive objects. See **Grounding** in the Operation manual.
- Use equipment only in well ventilated area.
- Eliminate all ignition sources, such as pilot lights, cigarettes and plastic drop cloths (potential static arc).
- Do not plug or unplug power cords or turn lights on or off when flammable fumes are present.
- Keep the work area free of debris, including solvent, rags, and gasoline.
- Hold gun firmly to side of grounded pail when triggering into pail.
- Use only grounded hoses.
- If there is static sparking or you feel a shock, **stop operation immediately**. Do not use equipment until you identify and correct the problem.
- To avoid chemical reaction and explosion, do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in pressurized aluminum equipment.

 <b>WARNING</b>	
	<p><b>EQUIPMENT MISUSE HAZARD</b></p> <p>Misuse can cause serious injury or death.</p> <ul style="list-style-type: none"> <li>• For professional use only.</li> <li>• Use equipment only for its intended purpose. Call your Graco distributor for information.</li> <li>• Read manuals, warnings, tags, and labels before operating equipment. Follow instructions.</li> <li>• Check equipment daily. Repair or replace worn or damaged parts immediately.</li> <li>• Do not alter or modify equipment. Use only Graco parts and accessories.</li> <li>• Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See <b>Technical Data</b> in all equipment manuals.</li> <li>• Use fluids and solvents that are compatible with equipment wetted parts. See <b>Technical Data</b> in all equipment manuals. Read fluid and solvent manufacturer's warnings.</li> <li>• Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.</li> <li>• Do not use hoses to pull equipment.</li> <li>• Comply with all applicable safety regulations.</li> </ul>
	<p><b>BURN HAZARD</b></p> <p>This equipment is used with heated fluid, which can cause equipment surfaces to become very hot. To avoid severe burns:</p> <ul style="list-style-type: none"> <li>• Do not touch hot fluid or equipment.</li> <li>• Allow equipment to cool completely before touching it.</li> <li>• Wear gloves if fluid temperature exceeds 110°F (43°C).</li> </ul>
	<p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read Material Safety Data Sheet (MSDS) to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> </ul>
	<p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>You must wear proper protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury; inhalation of toxic fumes; and hearing loss. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear.</li> <li>• Gloves, clothing, and respirator as recommended by the fluid and solvent manufacturer.</li> <li>• Hearing protection.</li> </ul>

# Before Beginning Repair

**WARNING**



Repairing this equipment requires access to parts which may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician connect power and ground to main power switch terminals, see the Operation manual. Be sure to shut off all power to the equipment before repairing.


**1.** Flush if necessary, see right.

**2.** Park component A pump.

a. Press .

b. Trigger gun until pump A stops. After fluid pressure drops below 700 psi (4.9 MPa, 49 bar), motor will run until component A pump is at bottom of its stroke, then shut off.


c. Check ISO reservoir for component A pump. Fill wet-cup on component B pump. See operation manual.

**3.** Turn main power OFF .

**4.** Relieve pressure, page 9.


# Flushing

**WARNING**



Read warnings, page 6. Flush equipment only in a well-ventilated area. Do not spray flammable fluids. Do not turn on heaters while flushing with flammable solvents.

- Flush out old fluid with new fluid, or flush out old fluid with a compatible solvent before introducing new fluid.
- Use the lowest possible pressure when flushing.
- All fluid components are compatible with common solvents. Use only moisture-free solvents.
- To flush feed hoses, pumps, and heaters separately from heated hoses, set PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE RELIEF.



- To flush entire system, circulate through gun fluid manifold (with manifold removed from gun).
- Always leave some type of fluid in system. Do not use water.



# Pressure Relief Procedure


1. Relieve pressure in gun and perform gun shutdown procedure. See gun manual.
2. Verify gun fluid manifold valves A and B are closed.



T12421A

3. Shut off feed pumps and agitator, if used.

4. Turn PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE RELIEF. Route fluid to waste containers or supply tanks. Ensure gauges drop to 0.




T12481A

5. Engage gun piston safety lock.



T12409A

6. Disconnect gun air line and remove gun fluid manifold.




T12543A

# Temperature Control Diagnostic Codes

Temperature control diagnostic codes E01 through E05 appear on temperature display.

These alarms turn off heat. Turn main power OFF



then ON



to clear.

Code No.	Code Name	Alarm Zone	Corrective Action page
01	High fluid temperature	Individual	10
02	High hose current	Hose only	10
03	No hose current with hose heater on	Hose only	11
04	FTS or thermocouple not connected	Individual	11
05	Board overtemperature	All	11



For hose zone only, if FTS is disconnected at startup, display will show hose current 0A.

## E01: High fluid temperature

- a. Check connections between temperature control board and heater overtemperature switches, page 38.
- b. Check temperature sensors, page 37.
- c. Check temperature sensor is contacting heater element, page 37.

## E02: High hose current

- a. Check tap connection at transformer, see operation manual.
- b. Check hose connections for electrical short, page 39.
- c. Move to lower hose length on transformer.
- d. Replace temperature control board, page 34.

## E03: No hose current

Do steps in order. Do not skip any step.

- a. Check hose connectors for broken electrical connection, page 39.
- b. Test hose continuity, page 42.
- c. Test transformer wire harness continuity, page 42.
- d. Check 50A (806) and 20A (817A) circuit breakers, page 28.
- e. Test current sensor continuity, page 42.
- f. Do **Transformer Primary Check**, page 44.
- g. Do **Transformer Secondary Check**, page 44.
- b. Check cable connections between all hose lengths.
- c. Check temperature sensor connection at J1 on temperature control board, page 34.
- d. Check thermocouple with ohmmeter, page 40.
- e. Use manual current control mode; see operation manual.

## E04: FTS or thermocouple not connected


- a. Check FTS operation by connecting directly to Reactor.


## E05: Board overtemperature

- a. Check fan operation.
- b. Check electrical cabinet door is properly installed.
- c. Check for obstructions blocking cooling holes in bottom of Reactor.
- d. Ambient temperature too high. Reduce gun mix chamber size, or move Reactor to a cooler location.

# Motor Control Diagnostic Codes

Motor control diagnostic codes E21 through E29 appear on pressure display.

 Alarms can also be cleared, except for code 23,


by pressing .

There are two types of motor control codes: alarms and warnings. Alarms take priority over warnings.

## Warnings

## Alarms


Alarms turn off Reactor. Turn main power OFF



then ON




to clear.

Reactor will continue to run. Press  to clear. A

warning will not recur for a predetermined amount of time (varies for different warnings), or until main power

is turned OFF



then ON



.

Code No.	Code Name	Alarm (A) or Warning (W)	Corrective Action page
21	No transducer (component A)	A	13
22	No transducer (component B)	A	13
23	High pressure	A	13
24	Pressure imbalance	A/W (to select, see page 30)	13
25	High line voltage	A	14
26	Low line voltage	A	14
27	High motor temperature	A	14
28	High current	A	14
29	Brush wear	W	14

## E21: No component A transducer

- Check transducer A connection at motor control board, page 31.
- Reverse A and B transducer connections. If error moves to transducer B (E22), replace transducer A, page 32.

## E22: No component B transducer

- Check transducer B connection at motor control board, page 31.
- Reverse A and B transducer connections. If error moves to transducer A (E21), replace transducer B, page 32.

## E23: High pressure

Relieve pressure. Verify low pressure with analog gauges. Turn main power OFF



then ON





. If error persists, do checks below.

- Check jumper on motor control board J10, pins 7-10, page 30.
- Replace motor control board, page 30.




## E24: Pressure imbalance

A and B pressures are imbalanced. Secure bleed lines in grounded waste containers, or route back to respective component A or B supply drum. Reduce pressure of higher component by **slightly** turning PRESSURE RELIEF/SPRAY valve for that component toward PRESSURE RELIEF, until gauges show balanced pressures.

 Turn valve slightly to reduce pressure of higher component.



TI2483A

-  Turn PRESSURE RELIEF/SPRAY valve only enough to balance pressure. If you turn it completely, all pressure will bleed off.
-  Jog and park modes may be run with pressure imbalance.
-  E24 can be an alarm or a warning, as desired. Set DIP switch on motor control board ON for alarm, OFF for warning. See page 30.

## E25: High line voltage

Supply voltage too high. Check Reactor voltage requirements, page 69.

## E26: Low line voltage

Supply voltage too low. Check Reactor voltage requirements, page 69.

## E27: High motor temperature

- a. Motor temperature too high. Reduce pressure, gun tip size, or move Reactor to a cooler location. Allow 1 hour for cooling.
- b. Check fan operation.
- c. Check motor sensor and connection to board (J7, pins 1, 2), page 30.

## E28: High current in motor

- a. Short on motor control board. Replace board, page 30.
- b. Replace motor, page 29.

## E29: Brush wear

Brush sensor contacting motor commutator. Replace brushes within 50 hours of operation after warning occurs. See pages 26, 29.




### CAUTION

Prolonged operation of motor after a brush wear warning may result in failure of motor and motor control board.






A series of horizontal lines spanning the width of the page, providing a template for handwritten notes or entries.



# Troubleshooting

PROBLEM	CAUSE	SOLUTION
Reactor does not operate.	No power.	Plug in power cord.
		Turn main power ON 
		Turn circuit breakers ON, page 28.
	Red stop button circuit open.	Check button connections. See page 46 and electrical diagrams.
Motor does not operate.	Loose connections.	Check connections at motor control board.
	Circuit breaker tripped.	Reset breaker (CB5), page 28. Check 230Vac at output of breaker.
	Worn brushes.	Check both sides. Length must be 0.7 in. (17 mm) minimum. To replace, page 26.
	Broken or misaligned brush springs.	Realign or replace, page 26.
	Brushes or springs binding in brush holder.	Clean brush holder and align brush leads for free movement.
	Shorted armature.	Replace motor, page 29.
	Check motor commutator for burn spots or other damage.	Remove motor. Have motor shop resurface commutator, if possible.
	Damaged motor control board.	Replace board. See page 30.
Fan not working.	Blown fuse.	Replace, page 33.
	Loose wire.	Check.
	Defective fan.	Replace, page 33.
Pump output low.	Obstructed fluid hose or gun; fluid hose ID too small.	Open, clear; use hose with larger ID.
	Worn piston valve or intake valve in displacement pump.	See pump manual.
	Pressure setpoint too high.	Reduce setpoint and output will increase.
Fluid leak in pump packing nut area.	Worn throat seals.	Replace. See pump manual.
No pressure on one side.	Fluid leaking from heater inlet rupture disk (214).	Check if heater (2) and PRESSURE RELIEF/SPRAY valve (SA or SB) are plugged. Clear. Replace rupture disk (214) with a new one; do not replace with a pipe plug.



PROBLEM	CAUSE	SOLUTION
No display.	Main power OFF.	Turn main power ON 
	Loose display cable.	Check cable connections, page 46.
	Both display boards failed.	Check boards, replace; page 46.
No temperature display.	Loose display cable.	Check cable connections, page 46.
	Failed temperature control board.	Open cabinet. Check if board LED is blinking. If not, check power wiring connections to ensure board has power. If board has power and LED is not blinking, replace board, page 34.
	Inadequate power to temperature board.	Check that power supply meets requirements.
	Loose power cable (internal to display).	Check cable connections, page 46.
	Defective display board.	Replace, page 46.
No pressure display.	Loose display cable.	Check cable connections, page 46.
	Failed motor control board.	Open cabinet. Check if board LED is lighted. If not, replace board, page 30.
	Inadequate power to motor control board.	Check that power supply meets requirements.
	Loose power cable.	Check cable connections, page 46.
	Defective display board.	Replace, page 46.
	Circuit breaker tripped.	Reset breaker.
Hose display reads 0A on startup.	FTS not installed and  zone off.	Install FTS (see operation manual), or adjust current to desired setting.
Erratic display; display turns on and off	Cable not grounded.	Ground cable, page 46.
	Extension cable too long.	Must not exceed 100 ft (30.5 m).
Display buttons do not work properly; cannot get out of an operation.	Broken membrane switch.	Replace, page 46.
	Ribbon cable disconnected or broken.	Connect cable, or replace.
Red stop button does not work.	Broken button (fused contact).	Replace, page 46.
	Loose wire.	Check connections, page 46.

PROBLEM	CAUSE	SOLUTION
No heat in A or B zones	Circuit breaker(s) tripped.	Reset breaker CB3 or CB4, page 28.
	Heat turned off.	Press <b>A</b> or <b>B</b> zone  keys.
	Temperature control alarm.	Check temperature displays for diagnostic code, page 10.
	Defective heater.	Replace, page 36. Check resistance.
	Loose connectors or wire nuts.	Check connections.
	Failed temperature control board.	Open cabinet. Check if board LED is blinking. If not, check power wiring connections to ensure board has power. If board has power and LED is not blinking, replace board, page 34.
Low heat in A or B zones	A and B temperature setpoints too low.	Check setpoint. Increase if necessary.
	Flow too high.	Use smaller mix chamber. Decrease pressure.
	Defective heater.	Replace, page 36. Check resistance.
	Loose connectors or wire nuts.	Check connections.
	Low voltage.	Check that power supply meets requirements.
	Overheated temperature control board.	Check fan operation.
		Check if door is open; close.
		Check that cooling holes are not clogged or obstructed.
Fluid too cold.	Preheat fluid.	

PROBLEM	CAUSE	SOLUTION
No hose heat	Loose hose electrical connections.	Check connections. Repair as necessary.
	Circuit breakers tripped.	Reset breakers (CB1 or CB2), page 28.
	Hose zone not turned on.	Press  zone  key.
	A and B temperature setpoints too low.	Check. Increase if necessary.
	Failed temperature control board.	Open cabinet. Check if board LED is blinking. If not, check power wiring connections to ensure board has power. If board has power and LED is not blinking, replace board, page 34.
Low hose heat.	A and B temperature setpoints too low.	Increase A and B setpoints. Hose designed to maintain temperature, not increase temperature.
	Hose temperature setpoint too low.	Check. Increase if necessary to maintain heat.
	Flow too high.	Use smaller mix chamber. Decrease pressure.
	Low current; FTS not installed.	Install FTS, see operation manual.
	Hose heat zone not turned on long enough.	Allow hose to heat up, or preheat fluid.
	Loose hose electrical connections.	Check connections. Repair as necessary.


# Repair

## Pump Removal

### WARNING




Pump rod and connecting rod move during operation. Moving parts can cause serious injury such as pinching or amputation. Keep hands and fingers away from connecting rod during operation.

 See manual 309577 for pump repair instructions.


1. Shut off **A** , **B** , and **Q** heat zones.

2. Flush pump, page 8.

3. If pumps are not parked, press  Trigger gun until pumps stop.


4. Turn main power OFF  . Disconnect power supply.

5. Shut off both feed pumps. Close both fluid inlet ball valves (B).





TI4174a

6. Turn both PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE RELIEF. Route fluid to waste containers or supply tanks. Ensure gauges drop to 0.




TI2481A


 Use dropcloth or rags to protect Reactor and surrounding area from spills.

 Steps 7-9 apply to pump A. See FIG. 1. To disconnect pump B, go to steps 10 and 11.


7. Disconnect fittings at fluid inlet (C) and outlet (D, out of view). Also disconnect steel outlet tube from heater inlet.
8. Disconnect tubes (T). Remove tube fittings (U) from wet-cup.
9. Loosen locknut (G) by hitting firmly with a non-sparking hammer. Unscrew pump far enough to separate and push up finger guard (P), to expose rod retaining pin. Push retaining wire clip up. Push pin out. Continue unscrewing pump.



**FIG. 1. Disconnect Pump A**


 Steps 10 and 11 apply to pump B. See FIG. 2.

10. Disconnect fluid inlet (C) and outlet (D). Also disconnect steel outlet tube from heater inlet.
11. Push retaining wire clip (E) up. Push pin (F) out. Loosen locknut (G) by hitting firmly with a non-sparking hammer. Unscrew pump.



**FIG. 2. Disconnect Pump B**

## Pump Installation

 Steps 1-5 apply to pump B. See FIG. 3. To reconnect pump A, go to step 6 on page 23.


1. Ensure locknut (G) is screwed on pump with flat side up. Screw pump into bearing housing (M) until pin holes align. Push pin (F) in. Pull retaining wire clip (E) down.

2. Continue screwing pump into housing until fluid outlet (D) is aligned with steel tube and top threads are +/- 1/16 in. (2 mm) of bearing face (N).

3. Tighten locknut (G) by hitting firmly with a non-sparking hammer.


4. Reconnect fluid inlet (C) and outlet (D).

5. Go to step 13, page 23.




TI3765a-1

**FIG. 3. Reconnect Pump B**


 Steps 6-12 apply to pump A only. See FIG. 4.


6. Ensure star-shaped locknut (G) is screwed on pump with flat side up. Carefully twist and extend displacement rod 2 in. (51 mm) above wet-cup.
7. Start threading pump into bearing housing (M). Place finger guard (P) over rod when it is accessible through window of bearing housing. When pin holes align, insert pin. Pull retaining wire clip down.


 Finger guard is not used on Model E-30.


8. Seat finger guard (P) on wet-cup. Continue threading pump into bearing housing (M) until top threads are +/- 1/16 in. (2 mm) of bearing face (N). Ensure that barbed fittings at wet-cup flush ports are accessible.


9. Connect component A outlet tube loosely at pump and at heater. Line up tube, then tighten fittings securely.
10. Tighten star-shaped locknut (G) by hitting firmly with a non-sparking hammer.
11. Apply thin film of TSL to barbed fittings. Using two hands, support tubes (T) while pushing straight onto barbed fittings. **Do not let tubes kink or buckle.** Secure each tube with a wire tie between two bars.
12. Reconnect fluid inlet (C).
13. Purge air and prime the system. See Reactor operation manual.

 Flat side faces up.

 Lubricate threads with ISO oil or grease.

 Pump top threads must be nearly flush with bearing face (N).

 Finger guard (P) not used on Model E-30.



T13765a-2


**FIG. 4. Reconnect Pump A**

# Drive Housing

## Removal

1. Turn main power OFF . Disconnect power supply.

2. Relieve pressure, page 9.
3. Remove screws (38) and motor shield (9), page 49.
4. Remove screws (309) and front cover (317), FIG. 5.


-  Examine bearing housing (303) and connecting rod (305). If these parts need replacing, first remove the pump (306), page 20.


5. Disconnect pump inlet and outlet lines. Remove screws (313), washers (315), and bearing housing (303).

### CAUTION

Do not drop gear cluster (304) when removing drive housing (302). Gear cluster may stay engaged in motor front end bell (R) or drive housing.


6. Remove screws (312, 319) and washers (314) and pull drive housing (302) off motor (301).

-  The A side drive housing includes cycle counter switch (321). If replacing this housing, remove pins (P) and switch. Reinstall pins and switch on new drive housing. Switch wires connect to J10 pins 5 and 6 on motor control board, page 30.




## Installation

1. Apply grease liberally to washers (307, 308, 318), all gears, and inside drive housing (302).
2. Install one bronze washer (308) in drive housing, then install steel washers (307, 318) as shown.
3. Install second bronze washer (308) on gear cluster (304) and insert gear cluster in drive housing.

-  Drive housing crankshaft (S) must be in line with crankshaft at other end of motor.

4. Push drive housing (302) onto motor (301). Install screws (312, 319) and washers (314).


-  If bearing housing (303), connecting rod (305), or pump (306) were removed, reassemble rod in housing and install pump, page 20.

5. Install bearing housing (303), screws (313), and washers (315). Pumps must be in phase (both at same position in stroke).

6. Install front cover (317) and screws (309).

7. Install motor shield (9) and screws (38).






TI3152A


**FIG. 5. Drive Housing**


# Motor Brushes

## Brush Removal

 Replace brushes worn to less than 1/2 in. (13 mm). Brushes wear differently on each side of motor; check both sides. Brush Repair Kit 234037 is available.


1. Turn main power OFF . Disconnect power supply.


 **WARNING**




Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Remove motor cover, screw, and washers. Remove inspection covers, screws, and gaskets from each end of motor.
4. Push in spring clip (C) to release hooks (H) from brush holder. Pull out clip and spring (S).




 One brush has a wire on top for brush wear signal. Note which side of motor it is on. Unplug at spade connector provided.

5. Loosen terminal screw (R). Pull away brush lead (L), being careful motor lead terminal (T) remains in place. Remove and discard brush (B).




6. Inspect commutator for excessive pitting, burning, or gouging. Black color on commutator is normal. Have commutator resurfaced by qualified motor repair shop if brushes wear too quickly.
7. Repeat for other side.


## Brush Installation

 **CAUTION**


When installing brushes, follow steps carefully. Improper installation damages parts beyond use.

 Install brush with wires on same side of motor as before. Plug spade terminal into connector.

1. Install new brush (B) so lead (L) is in long slot (D) of holder.




- Slide terminal (L) under terminal screw (R). Make sure motor lead terminal (T) is still connected at screw. Tighten screw.




01227-4

- Install spring clip (C) and push in until hooks (H) catch slots in housing. Incorrect installation may jam clip




01227-2



01227-6

- Install spring (S) so it will uncoil onto brush (B), as shown. Spring will be damaged if installed backwards.



Note direction of spring coil.

01227-6

**WARNING**

Do not touch brushes, leads, springs, or brush holders while equipment is plugged in, to reduce the risk of electric shock and serious injury.

**CAUTION**


Do not run pumps dry for more than 30 sec while checking brushes, to avoid damaging pumps.

- Reinstall brush inspection covers, gaskets, and screws. Reinstall motor cover, screws, washers, and drive housing/pump assemblies.
- Test brushes with both pump pins (F) disconnected, page 20.


Select J 1 (jog mode). Press motor to start motor. Slowly increase jog setting to J 6. Inspect brush and commutator contact area for excessive arcing. Arcs should not “trail” or circle around commutator surface.

Run motor for 20-30 min at J 6 to seat brushes.

# Circuit Breaker Module

1. Turn main power OFF . Disconnect power supply. Turn circuit breakers on to test.

**WARNING**



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).


2. Relieve pressure, page 9.

3. Using an ohmmeter, check for continuity across circuit breaker (top to bottom). If no continuity, trip breaker, reset, and retest. If still no continuity, replace breaker as follows:
  - a. Refer to electrical diagrams and to TABLE 1. Disconnect wires and remove bad breaker.
  - b. Install new breaker and reconnect wires.

**Table 1: Circuit Breakers, see FIG. 6**

Ref. No.	Size	Component
806	50 A	Hose/Transformer Secondary Side
817A	20 A	Transformer Primary
804A	25 or 40 A*	Heater A
804B	25 or 40 A*	Heater B
817B	20 A	Motor/Pumps

\* Depending on model.



**NOTE:** To reference cables and connectors, see the electrical diagrams and the parts drawings on pages 64-66.

TI2514A

**FIG. 6. Circuit Breaker Module**

# Electric Motor

## Removal

1. Turn main power OFF . Disconnect power supply.

### WARNING



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Remove drive housing/pump assemblies, page 24.
4. Disconnect motor cables as follows:
  - a. Refer to electrical diagrams. Motor control board is on right side inside cabinet, see page 30.
  - b. Unplug motor power harness from connector J4 on board. See FIG. 7, page 31.

- c. Unplug 3-pin connector J7 from board.
- d. Thread cables through top of cabinet to free motor.

### CAUTION


Motor is heavy. Two people may be required to lift.

5. Remove screws holding motor to cabinet. Lift motor off unit.

## Installation

1. Place motor on unit. Thread motor cables into cabinet and into bundles as before. See electrical diagrams.
2. Fasten motor with screws.
3. Plug 3-pin connector J7 to board.
4. Plug motor power harness to connector J4 on board.
5. Install drive housing/pump assemblies, page 24.
6. Return to service.

## Motor Control Board

 Motor control board has one red LED (D11 for 245980, D7 for 245981). Power must be on to check. See FIG. 7 for location. Function is:

- Startup: 1 blink for 60 Hz, 2 blinks for 50 Hz.
- Motor running: LED on.
- Motor not running: LED off.
- Diagnostic code (motor not running): LED blinks diagnostic code (for example, E21=21 blinks).

### CAUTION

Before handling board, put on a static conductive wrist strap to protect against static discharge which can damage board. Follow instructions provided with wrist strap.



1. Turn main power OFF . Disconnect power supply.

### WARNING



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Refer to electrical diagrams. Motor control board is on right side inside cabinet.
4. Put on static conductive wrist strap.
5. Disconnect all cables and connectors from board.
6. Remove nuts (42) and take entire motor control assembly to workbench.
7. Remove screws and take board off heatsink.

8. Set DIP switch (SW2) on new board. See below for factory settings. See FIG. 7 for location on board.

### WARNING



Read warnings, page 6. To prevent overpressurization, DIP switch 2 must be set to ON for Models E-20 and E-30.

- Switch 1: not used.
  - Switch 2: ON for Models E-20 and E-30, OFF for Models E-XP1 and E-XP2.
  - Switch 3: ON for pressure imbalance alarm, OFF for pressure imbalance warning.
  - Switch 4: not used.
9. Install new board in reverse order. Apply thermal heatsink compound to mating surfaces of board and heatsink.



Order Part No. 110009 Thermal Compound.

**Table 2: Motor Control Board Connectors**

Model E-20 and E-XP1	Model E-30 and E-XP2	Pin	Description
J1	N, L	n/a	Main motor power
J3	J3	n/a	Transducer A
J4	J1	n/a	Motor output
J7	J6	1, 2	Motor thermal overload signal
		3	Brush wear signal
J8	J5	n/a	Transducer B
J10	J7	1-4	Not used
		5, 6	Cycle switch signal
		7-10	Jumper 15C866 (available in repair kit 246961)
J12	J12	n/a	Data reporting
J13	J13	n/a	To display board

**245980 Motor Control, for E-20 and E-XP1**

**DIP Switch (SW2) Settings**

**Model E-20**

**ON**




1 2 3 4 TI3178b-3

**Model E-XP1**

**ON**



1 2 3 4 TI3178b-4



**245981 Motor Control, for E-30 and E-XP2**

**DIP Switch (SW2) Settings**

**Model E-30**

**4 3 2 1**




ON TI3178b-2


**Model E-XP2**

**4 3 2 1**



ON TI3178b-1




 Apply 110009 thermal heatsink compound to mating surfaces.

**FIG. 7. Motor Control Board**

# Transducers

1. Turn main power OFF . Disconnect power supply.


**⚠ WARNING**



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Refer to electrical diagrams. Motor control board is on right side inside cabinet.

4. Disconnect transducer cables at board; see FIG. 7, page 31. Reverse A and B connections and check if diagnostic code follows, page 13.
5. If transducer fails test, thread cable through top of cabinet. Note path as cable must be replaced in same way.
6. Install o-ring (720) on new transducer (706), FIG. 8.
7. Install transducer in manifold. Mark end of cable with tape (red=transducer A, blue=transducer B).
8. Route cable into cabinet and thread into bundle as before.
9. Connect transducer cable at board; see FIG. 7, page 31.



TI3169a

**FIG. 8. Transducers**



# Fan


1. Turn main power OFF . Disconnect power supply.

## WARNING



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).


2. Relieve pressure, page 9.
3. Check fuses (F) at left of breaker module, FIG. 9. Replace if blown. If good, continue with step 4.
4. Refer to electrical diagrams. Disconnect fan wires from fuses (F). Thread wires through top of cabinet.
5. Remove fan.
6. Install fan in reverse order.



TI2514A-1

**FIG. 9. Fan Fuses**

# Temperature Control Board

 Temperature control board has seven green LEDs. Power must be on to check. See FIG. 7 for location.

**Table 3: Temperature Control Board LEDs**

LED	Status	Function
D26	blinks	Board powered
D14	on	Zone A turned on
D13	cycles on and off	Zone A powered, LED cycles as temperature cycles
D18	on	Zone B turned on
D19	cycles on and off	Zone B powered, LED cycles as temperature cycles
D27	on	Hose zone turned on
D15	cycles on and off	Hose zone powered, LED cycles as temperature cycles

## CAUTION

Before handling board, put on a static conductive wrist strap to protect against static discharge which can damage board. Follow instructions provided with wrist strap.

1. Turn main power OFF . Disconnect power supply.

## WARNING



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).


- Relieve pressure, page 9.
- Refer to electrical diagrams. Temperature control board is on left side inside cabinet.
- Put on static conductive wrist strap.
- Disconnect all cables and connectors from board, FIG. 10.
- Remove nuts and take entire temperature control assembly to workbench.
- Remove screws and take board off heatsink.
- Install new board in reverse order. Apply thermal heatsink compound to mating surfaces of board and heatsink.




Order Part No. 110009 Thermal Compound.

**Table 4: Temperature Control Board Connectors**

Connector	Pin	Description	
J1	1, 2	Overtemperature switch A	
	3, 4	Overtemperature switch B	
	5, 6	Current sensor	
	7	Temperature sensor A, red	
	8	Temperature sensor A, yellow	
	9	Not used	
	10	Temperature sensor B, red	
	11	Temperature sensor B, yellow	
	12	Thermocouple, silver	
	13	Thermocouple, red	
	14	Thermocouple, purple	
	J2	n/a	To A heaters
	J5	n/a	To display board
	J8	n/a	Data reporting
J9	n/a	To B heaters	
J13	n/a	To heated hose	

 Apply 110009 thermal heatsink compound to mating surfaces.



TI2572a

**FIG. 10. Temperature Control Board**


# Heater

## Heater Element

1. Turn main power OFF . Disconnect power supply.


2. Relieve pressure, page 9.

**WARNING**



Read warnings, page 7. Wait for heaters to cool before repairing.

3. Wait for heaters to cool.
4. See FIG. 11. Remove tape and wire connector (63, not shown), and disconnect heater element wires (W) from heater wire harness. Test with ohmmeter. Resistance must be 21-25 ohms for 2550W element, and 30-34 ohms for 1500W element.
5. If heater fails test, remove temperature sensor (211) to avoid damage.
6. Remove heater element (207) from tube (201). Be careful not to spill any fluid left in tube.
7. Install new heater element (207), holding mixer (202) so it does not interfere with sensor port (P).
8. Reinstall temperature sensor, page 37.
9. Reconnect wires and secure with connector (63) and electrical tape.



TI2512b

**FIG. 11. Heater (Model 245962 Shown)**

## Temperature Sensor

1. Turn main power OFF . Disconnect power supply.

2. Relieve pressure, page 9.

### WARNING





Read warnings, page 7. Wait for heaters to cool before repairing.

3. Wait for heaters to cool.
4. Disconnect temperature sensor wires from J1 on temperature control board. See TABLE 4, page 34 and FIG. 10, page 35.
5. See FIG. 12. Test with ohmmeter. Between wires (S), resistance must be approximately 6 ohms. Between tip (T) and wires, resistance must be infinity ( $\infty$ ).
6. If sensor fails test, feed wires out of cabinet. Note path as wires must be replaced in the same way.
7. Loosen ferrule nut (N). Remove temperature sensor (211) from heater tube (201), then remove sensor housing (H).
8. Replace sensor, FIG. 12.
  - a. Remove protective tape from sensor tip (T).
  - b. To ensure mixer (202) is out of the way, insert 1/4 in. drill bit into heater tube (201) to a minimum depth of 0.81 in. (20.6 mm). If minimum is not achieved, mixer must be moved before proceeding.

- c. Apply PTFE tape and thread sealant to male threads and tighten sensor housing (H) into tube (201).
  - d. Push in sensor (211) so tip (T) contacts heater element (207), avoiding mixer (202).
  - e. Tighten ferrule nut (N), holding sensor (T) against heater element.
9. Route wires into cabinet and thread into bundle as before. Reconnect wires to board.
  10. Turn on heaters A and B simultaneously to test. Temperatures should rise at same rate (30°F, +/- 4°). If one heater is low, loosen ferrule nut (N) and tighten sensor housing (H) to ensure sensor tip (T) contacts element (207).

 Apply PTFE tape and thread sealant.

 Apply 110009 thermal heatsink compound.



TI3249a

**FIG. 12. Temperature Sensor**

## Overtemperature Switch

1. Turn main power OFF . Disconnect power supply.

2. Relieve pressure, page 9.



### WARNING




Read warnings, page 7. Wait for heaters to cool before repairing.

3. Wait for heaters to cool.
4. Disconnect one leadwire from overtemperature switch (208), FIG. 12. Test across switch with ohmmeter. Resistance must be approximately 0 ohms.
5. If switch fails test, cut off clamps with wire clippers. Remove switch. Install new switch in same location on tube (201) and secure with hose clamps (203). Reconnect wires.



If wires need replacement, disconnect from temperature control board. See TABLE 4, page 34 and FIG. 10, page 35.


# Heated Hose

 Refer to the heated hose manual 309572 for hose replacement parts.

## Check Hose Connectors

1. Turn main power OFF . Disconnect power supply.

2. Relieve pressure, page 9.

 Whip hose must be connected.

3. Disconnect hose electrical connector (D) at Reactor, FIG. 13.

4. Using an ohmmeter, check between the two terminals of hose connector (D). There should be continuity.

5. If hose fails test, retest at each length of hose, including whip hose, until failure is isolated.

## Check FTS Cables


1. Turn main power OFF . Disconnect power supply.

2. Relieve pressure, page 9.

3. Disconnect FTS cable (F) at Reactor, FIG. 13.
4. Test with ohmmeter between pins of cable connector.

Pins	Result
1 to 2	approximately 35 ohms per 50 ft (15.2 m) of hose, plus approximately 10 ohms for FTS
1 to 3	infinity ( $\infty$ )

5. If cable fails test, retest at FTS, page 40.




T12726a

**FIG. 13. Heated Hose**

# Fluid Temperature Sensor (FTS)

## Test/Removal

1. Turn main power OFF . Disconnect power supply.
2. Relieve pressure, page 9.
3. Remove tape and protective covering from FTS (11), FIG. 14. Disconnect hose cable (F). Test with ohmmeter between pins of cable connector.

Pins	Result
1 to 2	approximately 10 ohms
1 to 3	infinity ( $\infty$ )
3 to FTS groundscrew	0 ohms
1 to FTS component A fitting (ISO)	infinity ( $\infty$ )

4. If FTS fails test, replace FTS.
5. Disconnect air hoses (C, L), and electrical connectors (D).

6. Disconnect FTS from whip hose (W) and fluid hoses (A, B).
7. Remove ground wire (K) from ground screw on underside of FTS.
8. Remove FTS probe (H) from component A (ISO) side of hose.


## Installation

### CAUTION

To prevent damage to probe, do not kink or excessively bend whip hose. Do not coil hose tighter than the minimum bend radius of 3 ft (0.9 m). Do not subject hose to excessive weight, impact, or other abuse.

1. Carefully extend FTS probe (H). Do not bend or kink probe. Insert in component A (ISO) side of main hose.
2. Connect whip hose ground wire (K) to ground screw on underside of FTS.
3. Install FTS in reverse order of removal. Leave slack (G) in cables as stress relief, to prevent cable failure.
4. Secure hose and cable connections with tape and install protective covering.






TI2684a1


**FIG. 14. Fluid Temperature Sensor and Heated Hoses**

# Transformer

## Test Hose Continuity


1. Turn main power OFF . Disconnect power supply. Leave hose plugged in.
2. See FIG. 15. Disconnect 6-pin transformer connector (P) from J13 at temperature control board. Remove red wire from transformer hose length tap you are using (R).
3. Using an ohmmeter, check between pin 6 (P6) of connector (not board) and red wire. There should be continuity.
4. If test fails, trace wires until failure is located.

## Test Transformer Wire Harness Continuity


1. Turn main power OFF . Disconnect power supply. Leave hose plugged in.
2. See FIG. 15. Disconnect 6-pin transformer connector (P) from J13 at temperature control board.

3. Check for continuity between:
  - a. Connector pin 1 (P1) and T1 on 20A hose circuit breaker (817A).
  - b. Connector pin 3 (P3) and T2 on 20A hose circuit breaker (817A).
  - c. Connector pin 5 (P5) and T3 on 50A hose circuit breaker (806).


## Test Current Sensor Continuity

1. Turn main power OFF . Disconnect power supply.
2. Disconnect 14-pin connector from J1 on temperature control board, page 34.
3. Using an ohmmeter, test for continuity across pins 5 and 6 of connector (not board). Reading should be 20-25 ohms. If not, replace current sensor (32). See FIG. 15.

**Detail B: Circuit Breaker Module and Hose Heat Wire Harness**



TI4335A



TI3470b

**Part No. 15B352 Transformer (Models E-30 and E-XP2) shown**

**FIG. 15. Transformer Continuity Tests**



## Transformer Primary Check


1. Ensure that all harnesses, cables, and connectors are properly connected. Connect hose.


2. Connect power supply. Turn main power ON



3. Set hose heat target temperature below current hose temperature.

4. Turn on  heat zone by pressing .

 **WARNING**



Read warnings, page 6. Step 5 measures line voltage and should be done by a qualified electrician. If work is not performed properly it may cause electric shock or other serious injury.

5. See FIG. 15, Detail B. Measure voltage across pins P2 and P4 of six-pin connector on temperature control board. Measurement should be line voltage. If not, replace temperature control board, page 34.



## Transformer Secondary Check


1. Ensure that all harnesses, cables, and connectors are properly connected. Connect hose.


2. Connect power supply. Turn main power ON



3. Set hose heat target temperature below current hose temperature.

4. Turn on  heat zone by pressing .

 **WARNING**




Read warnings, page 6. Step 5 measures line voltage and should be done by a qualified electrician. If work is not performed properly it may cause electric shock or other serious injury.


5. See FIG. 16, Detail B. Measure voltage across transformer hose tap (R) you are using and top terminal (T4) on 50A hose circuit breaker (806). See TABLE 5 for readings. If reading is correct, replace temperature control board, page 34. If reading is wrong, replace transformer, page 45.

**Table 5: Transformer Voltage Readings**

Transformer Tap	Reading (VAC)
50'	20
100'	34
150'	48
200'	62
250'	76
300'	90

## Replace Transformer

 Use this procedure to replace transformer.

1. Turn main power OFF . Disconnect power supply.


### WARNING



Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Open Reactor cabinet.
3. Remove bolts holding transformer to cabinet floor. Slide transformer forward.
4. Unplug 2-pin wire harness connector (C) from wire harness coming from temperature control board.
5. Disconnect the transformer's secondary common wire (P) from T4 at 50 amp circuit breaker (806).
6. Remove transformer from cabinet.
7. Install new transformer in reverse order.

### Detail B: Circuit Breaker Module



Part No. 15B352 Transformer (Models E-30 and E-XP2) shown

FIG. 16. Transformer

# Display Module

## Temperature and Pressure Displays

### CAUTION

Before handling board, put on a static conductive wrist strap to protect against static discharge which can damage board. Follow instructions provided with wrist strap.


1. Turn main power OFF . Disconnect power supply.

### WARNING




Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Refer to electrical diagrams.
4. Put on static conductive wrist strap.
5. Disconnect main display cable (20) at lower left corner of display module, FIG. 17.
6. Remove screws (409, 410) and cover (404).


 If replacing both displays, label temperature display cables TEMP and pressure display cables PUMP before disconnecting.

7. Disconnect cable connectors J1 and J13 from back of temperature display (401) or pressure display (402).
8. Disconnect ribbon cable(s) (R) from back of display.
9. Remove nuts (408) and plate (405).
10. Disassemble display, see detail in FIG. 17.
11. Replace board (401a or 402a) or membrane switch (401b or 402b) as necessary.
12. Reassemble in reverse order, see FIG. 17. Apply medium strength thread sealant where shown. Be sure display cable ground wire (G) is secured between cable bushing and cover (404) with screws (412). Also check ground connection at rear of Reactor, see below.




TI13743a

⚠ Apply medium strength thread sealant.



TI2574A

**Detail of Membrane Switches and Display Boards**



TI3172a

**FIG. 17. Display Module**

## Red Stop Button

### CAUTION

Before handling board, put on a static conductive wrist strap to protect against static discharge which can damage board. Follow instructions provided with wrist strap.

1. Turn main power OFF  . Disconnect power supply.

### WARNING




Read warnings, page 6. Wait 5 min for stored voltage to discharge (E-30 and E-XP2 models only).

2. Relieve pressure, page 9.
3. Refer to electrical diagrams.
4. Put on static conductive wrist strap.
5. Remove screws (409, 410) and cover (404), FIG. 17.
6. Disconnect button cable connectors J1 from back of temperature display (401) and pressure display (402).
7. Remove red stop button (406).
8. Reassemble in reverse order. Be sure display cable ground wire (G) is secured between cable bushing and cover (404) with screws (412).




# Parts


## Reactor Assembly (Model E-XP1 Shown)




T13764a-1




T13764a



T13765a-2



T12606a



T12605A

# Reactor Assembly

## Parts that Vary by Model

Use the tables on this page and the next page to find parts that vary by model. Find the ref. no. of part in left column, and Reactor model in top row. Intersection is correct part no.

See page 54 for parts common to all models.

Ref. No.	Description	Reactor Models											Qty	
		246024 E-XP1	246025 E-20	246026 E-30	246028 E-XP2	246029 E-XP1	246030 E-20	246031 E-30	246032 E-XP2	246033 E-XP1	246034 E-20	246035 E-30		246036 E-XP2
2	HEATER; pages 55, 35	245962	245975	245962	245963 (qty: 2)	245962	245975	245962	245963 (qty: 2)	245962	245975	245962	245963 (qty: 2)	1
3	MODULE, proportioner; page 57	245956	245956	245957	245959	245956	245956	245957	245959	245956	245956	245957	245959	1
6	CONTROL, motor; page 61	245980	245980	245981	245981	245980	245980	245981	245981	245980	245980	245981	245981	1
8	TRANSFORMER;	15B351	15B351	15B352	15B352	15B351	15B351	15B352	15B352	15B351	15B351	15B352	15B352	1
9	SHIELD	276878	276878	276879	276879	276878	276878	276879	276879	276878	276878	276879	276879	1
14	TUBE, heater, component A	15B481	15B481	15B481	15B685	15B481	15B481	15B481	15B685	15B481	15B481	15B481	15B685	1
15	TUBE, pump, component A	15B367	15B367	15B480	15B686	15B367	15B367	15B480	15B686	15B367	15B367	15B480	15B686	1
16	TUBE, heater, component B	15B483	15B483	15B483	15B687	15B483	15B483	15B483	15B687	15B483	15B483	15B483	15B687	1
17	TUBE, pump, component B	15B369	15B369	15B482	15B688	15B369	15B369	15B482	15B688	15B369	15B369	15B482	15B688	1
21	CONNECTOR, tube	117555	117555	117594	117594	117555	117555	117594	117594	117555	117555	117594	117594	2
28	MODULE, breaker; page 64	246090	246090	246090	246092	246096	246096	246096	246098	246087	246087	246087	246089	1
36	SWITCH, added pole; 380V					117553	117553	117553	117553					1
39	FILTER; 230V			117667	117667			117667	117667			117667	117667	1

Ref. No.	Description	Reactor Models											Qty	
		246024 E-XP1	246025 E-20	246026 E-30	246028 E-XP2	246029 E-XP1	246030 E-20	246031 E-30	246032 E-XP2	246033 E-XP1	246034 E-20	246035 E-30		246036 E-XP2
51 ▲	LABEL, warning			198278	198278			198278	198278			198278	198278	1
52	CABLE, harness, filter			15B385	15B385			15B385	15B385			15B385	15B385	1
65	ELBOW, swivel; 3/4 npt(m) x 3/4 npt(f)	160327	160327		160327	160327	160327		160327	160327	160327		160327	2
	ELBOW, swivel; 3/4 npt(m) x 1" npt(f)			118463				118463				118463		2
71	SCREW, machine			104590	104590			104590	104590			104590	104590	2
72	BRACKET, heater	15C733	15C733	15C733		15C733	15C733	15C733		15C733	15C733	15C733		2
	BRACKET, heater				15C733				15C733				15C733	4
73	WASHER, lock			103181	103181			103181	103181			103181	103181	2
76	CAPACITOR			244733	244733			244733	244733			244733	244733	1
77	BRACKET			197999	197999			197999	197999			197999	197999	1
86	CABLE, overtemperature, jumper; see pages 55, 56)	15B769	15B769	15B769		15B769	15B769	15B769		15B769	15B769	15B769		2
	CABLE, overtemperature, jumper; see page 56)				15B769				15B769				15B769	4
92	CABLE, harness, power; see pages 64-66	15B511	15B511			15B511	15B511			15B511	15B511			1
	CABLE, harness, power; see pages 64-66			15B382	15B382			15B382	15B382			15B382	15B382	1
95	BOLT; hex hd; 3/8-16	516595	516595	516595		516595	516595	516595		516595	516595	516595		2
	BOLT; hex hd; 3/8-16				516595				516595				516595	4
96	LOCKWASHER; 3/8	100133	100133	100133		100133	100133	100133		100133	100133	100133		2
	LOCKWASHER; 3/8				100133				100133				100133	4
97	NUT, channel	118446	118446	118446		118446	118446	118446		118446	118446	118446		2
	NUT, channel				118446				118446				118446	4
102	STRAP, motor	15B107	15B107	15B108	15B108	15B107	15B107	15B108	15B108	15B107	15B107	15B108	15B108	1

## Reactor Assembly Parts Continued

Ref. No.	Description	Reactor Models			Qty
		248657 E-30 w/15.3 kW	248658 E-30 w/15.3 kW	248659 E-30 w/15.3 kW	
2	HEATER; pages 55, 35	245963	24962	245962	2
3	MODULE, proportioner; page 57	245957	245957	245957	1
6	CONTROL, motor; page 61	245981	245981	245981	1
8	TRANSFORMER;	15B352	15B352	15B352	1
9	SHIELD	276879	276879	276879	1
14	TUBE, heater, component A	15B685	15B685	15B685	1
15	TUBE, pump, component A	15B686	15B686	15B686	1
16	TUBE, heater, component B	15B687	15B687	15B687	1
17	TUBE, pump, component B	15B688	15B688	15B688	1
21	CONNECTOR, tube	117594	117594	117594	2
28	MODULE, breaker; page 64	246090	246089	246098	1
36	SWITCH, added pole; 380V			117553	1
39	FILTER; 230V	117667	117667	117667	1
51 ▲	LABEL, warning	198278	198278	198278	1
52	CABLE, harness, filter	15B385	15B385	15B385	1
65	ELBOW, swivel; 3/4 npt(m) x 3/4 npt(f)				

Ref. No.	Description	Reactor Models			Qty
		248657 E-30 w/15.3 kW	248658 E-30 w/15.3 kW	248659 E-30 w/15.3 kW	
	ELBOW, swivel; 3/4 npt(m) x 1" npt(f)	118463	118463	118463	2
71	SCREW, machine	104590	104590	104590	2
72	BRACKET, heater				
	BRACKET, heater	15C733	15C733	15C733	2
73	WASHER, lock	103181	103181	103181	2
76	CAPACITOR	244733	244733	244733	1
77	BRACKET	197999	197999	197999	1
86	CABLE, overtemperature, jumper; see pages 55, 56)				
	CABLE, overtemperature, jumper; see page 56)	15B769	15B769	15B769	4
92	CABLE, harness, power; see pages 64-66				
	CABLE, harness, power; see pages 64-66	15B382	15B382	15B382	1
95	BOLT; hex hd; 3/8-16				
	BOLT; hex hd; 3/8-16	516595	516595	516595	4
96	LOCKWASHER; 3/8				
	LOCKWASHER; 3/8	100133	100133	100133	4
97	NUT, channel				
	NUT, channel	118446	118446	118446	4
102	STRAP, motor	15B108	15B108	15B108	1


## Common Parts

Ref. No.	Part No.	Description	Qty	Ref. No.	Part No.	Description	Qty
1	245954	FRAME; page 55	1	57	15B775	COVER, wire access	2
4	245974	DISPLAY; page 59	1	58	246895	COVER, heater, back	1
5	245979	CONTROL, temperature; page 60	1	59	15B798	COVER, heater, front	1
7	246154	MANIFOLD, fluid; page 63	1	60▲	15B679	LABEL, warning	1
10	246976	DOOR, cabinet	1	61	113505	NUT, hex, keps; 10-24	6
11	246079	SENSOR, fluid temperature	1	62	112776	WASHER, plain; no. 10	2
12	15B456	GASKET, manifold	1	63	117722	CONNECTOR, wire; not shown, see electrical diagrams	4
13	115834	FAN	1	66	101078	Y-STRAINER; includes 66a	2
18	15B374	CABLE, overtemperature; not shown, see electrical diagrams	1	66a	180199	. ELEMENT, 20 mesh; not shown	1
19	15B380	CABLE, hose control; not shown, see electrical diagrams	1	67	109077	VALVE, ball; 3/4 npt (fbc)	2
20	15B383	CABLE, display	1	68	C20487	NIPPLE; 3/4 npt	2
22	116773	CONNECTOR, plug	1	69	157785	UNION, swivel; 3/4 npt(m) x 3/4 npsm(f)	2
23	C38163	WASHER, lock, external tooth	1	79	112512	FERRULE	2
24	15B361	BOOT, wire feed through	1	87	15B807	SHIELD, fan	1
25	15B510	PLATE, cover, wire	1	88	186494	CLIP, spring	6
26	15B360	GASKET, fan	1	89	205447	COUPLING, hose	2
27	117682	STRAIN RELIEF	1	90	buy locally	TUBE, low pressure; 1/4 in. (6 mm) ID; 3/8 in. (16 mm) OD; 4 ft (1.2 m); PTFE	1
29	116149	SPACER	8	106	117502	REDUCER; #5 x #8 JIC	1
31	117666	TERMINAL, ground	1	107	117677	REDUCER; #6 x #10 JIC	1
32	15B388	SENSOR, current, hose; not shown, see electrical diagrams	1	109	246928	RESERVOIR; includes 110-119; see 309911	1
33	117564	SWITCH, disconnect	1	110	054826	TUBE; PTFE; 1/4 in. (6 mm) ID; 2 ft (0.6 m)	2
34	117545	SWITCH, main power	1	111	118433	VALVE, check	1
35	117723	SCREW, machine; 6-32 x 2 in. (51 mm)	4	112	118432	VALVE, check	1
37	15B396	WIRE, hose	1	113	116746	FITTING, barbed	2
38	115492	SCREW, machine; 8-32 x 0.345 in. (9 mm)	13	115	15C568	BRACKET, reservoir	1
40	117623	NUT, cap; 3/8-16	4	116	186494	CLIP, spring	1
41	113796	SCREW, flanged, hex hd; 1/4-20 x 3/4 in. (19 mm)	15	117	206995	THROAT SEAL LIQUID; 1 qt (1 liter)	1
42	115942	NUT, hex flange; 1/4-20	15	119	191892	ELBOW; 1/8 npt (m x f)	2
44	15B536	LABEL, diagnostic codes	1	120▲	171001	LABEL, warning	1
45	189930	LABEL, caution	3				
48▲	189285	LABEL, caution	3				
53	15B593	SHIELD, membrane switch; pack of 10	1				

▲ Replacement Warning labels, signs, tags, and cards are available at no cost.

# Reactor Frame

## 245954 Frame




TI2513A

# Fluid Heater

## 245962 10.2 kW Heater, for E-30 and E-XP1 Reactor

\* Ref. No. 86 not included with heater.  
Order separately, see page 52.




TI2512b

Ref. No.	Part No.	Description
901	246204	FRAME
902	116478	WHEEL
903	101242	RING, retaining
904	116477	WASHER, flat; nylon
905	112125	PLUG
906	116411	SPRING
907	154636	WASHER, flat

Qty	Ref. No.	Part No.	Description	Qty
1	201	15B134	HOUSING	2
2	202	15B135	MIXER	4
2	203	118426	CLAMP	8
4	205	15B132	MANIFOLD	4
2	206	107218	SCREW	8
2	207	15B138	HEATER, immersion; 2550 W; 230v	4
4	208	15B137	SWITCH, overtemperature	4
	210	100361	PLUG	2
	211	117484	SENSOR, temperature	2
	213	117532	ELBOW; 1/2 npt x 1/2 in. (13 mm) OD tube	4
	214	248187	RUPTURE DISK KIT; see 309969	2

**245963 7.65 kW Heater, for E-XP2 and E-30, with 15.3kW of heat, Reactor (2 required)**

\* Ref. No. 86 not included with heater. Order separately, see page 52.




TI2578b

Ref. No.	Part No.	Description	Qty
201	15B134	HOUSING	2
202	15B135	MIXER	4
203	118426	CLAMP	6
204	15B133	CROSSOVER	2
205	15B132	MANIFOLD	2
206	107218	SCREW	8
207	15B138	HEATER, immersion; 2550 W; 230v	3
208	15B137	SWITCH, overtemperature	3
209	100139	PLUG	1
210	100361	PLUG	2
211	117484	SENSOR, temperature	1
212	117466	O-RING	1
213	117532	ELBOW; 1/2 npt x 1/2 in. (13 mm) OD tube	2
214	248187	RUPTURE DISK KIT; see 309969	1

**245975 6 kW Heater, for E-20 Reactor**

\* Ref. No. 86 not included with heater. Order separately, see page 52.



TI2512b

Ref. No.	Part No.	Description	Qty
201	15B134	HOUSING	2
202	15B135	MIXER	4
203	118426	CLAMP	8
205	15B132	MANIFOLD	4
206	107218	SCREW	8
207	15B140	HEATER, immersion; 1500 W; 230v	4
208	15B137	SWITCH, overtemperature	4
210	100361	PLUG	2
211	117484	SENSOR, temperature	2
213	117532	ELBOW; 1/2 npt x 1/2 in. (13 mm) OD tube	4
214	248187	RUPTURE DISK KIT; see 309969	2




# Proportioner Module

245956 Module, for E-20 and E-XP1


245957 Module, for E-30

245959 Module, for E-XP2



△ Flat side faces up.

## Detail of Cycle Counter Switch



TI2511A

TI3250a

**245956 Module, for E-20 and E-XP1****245957 Module, for E-30****245959 Module, for E-XP2**


Ref. No.	Part No.	Description	Qty	Ref. No.	Part No.	Description	Qty
301	245965	MOTOR; 245956	1	312	107218	SCREW, cap, socket-hd; 1/4-20 x 2-3/4 in. (70 mm); 245956	4
	245966	MOTOR; 245957, 245959	1		114686	SCREW, cap, socket-hd; 5/16-18 x 3-1/4 in. (83 mm); 245957, 245959	4
302	245968	HOUSING, drive; 245956	2	313	107210	SCREW, cap, socket-hd; 3/8-16 x 1-1/2 in. (38 mm); 245956	8
	245969	HOUSING, drive; 245957, 245959	2		114666	SCREW, cap, socket-hd; 3/8-16 x 2-1/4 in. (57 mm); 245957, 245959	8
303	240523	HOUSING, bearing; 245956	2	314	105510	WASHER, lock; 1/4; 245956	12
	241015	HOUSING, bearing; 245959	2		104008	WASHER, lock; 5/16; 245957, 245959	12
	245927	HOUSING, bearing; 245957	2	315	106115	WASHER, lock; 3/8 size	8
304	244264	GEAR; includes items 307, 308; 245956	2	316	192723	NUT, retaining; 245956	2
	244265	GEAR; includes items 307, 308; 245957, 245959	2		193031	NUT, retaining; 245959	2
305	241008	ROD, connecting; includes item 310; 245956	2		193394	NUT, retaining; 245957	2
	241279	ROD, connecting; includes item 310; 245957, 245959	2	317	179899	COVER; 245956	2
306A	246830	PUMP, displacement, component A; 245956; see 309577	1		241308	COVER; 245957, 245959	2
	246831	PUMP, displacement, component A; 245959; see 309577	1	318	116191	WASHER, thrust; 245956	2
	246832	PUMP, displacement, component A; 245957; see 309577	1		116192	WASHER, thrust; 245957, 245959	2
306B	245970	PUMP, displacement, component B; 245956; see 309577	1	319	100644	SCREW, cap, socket-hd; 1/4-20 x 3/4 in. (19 mm); 245956	4
	245971	PUMP, displacement, component B; 245959; see 309577	1		101864	SCREW, cap, socket-hd; 5/16-18 x 1 in. (25 mm); 245957, 245959	4
	245972	PUMP, displacement, component B; 245957; see 309577	1	320	116618	MAGNET	1
307*	114699	WASHER, thrust; steel	2	321	117770	SWITCH, cycle counter	1
308*	114672	WASHER, thrust; bronze	4	323	100643	SCREW, cap, socket-hd; 1/4-20 x 1 in. (25 mm); 245956	4
309	114418	SCREW, self-tapping; 8-32 x 1 in. (25 mm); 245956	8		102962	SCREW, cap, socket-hd; 5/16-18 x 1-1/4 in. (31 mm); 245957, 245959	4
	114818	SCREW, self-tapping; 8-32 x 1-1/4 in. (31 mm); 245957, 245959	8	324	104765	PLUG	2
310**	176817	CLIP, wire; 245956	2	325	15C587	GUARD, finger; 245956	1
	183169	CLIP, wire; 245957, 245959	2		15C588	GUARD, finger; 245959	1
311	176818	PIN; 245956	2				
	183210	PIN; 245957, 245959	2				

\* Parts included in Gear Kit 244264 (245956) or 244265 (245957, 245959).


\*\* Parts included in Connecting Rod Kit 241008 (245956) or 241279 (245957, 245959).

# Display

## 245974 Display



TI2574A





TI3172a

Ref. No.	Part No.	Description	Qty	Ref. No.	Part No.	Description	Qty
401	245978	DISPLAY, pressure; includes 401a-401c	1	403	15B293	GASKET	1
401a	246130	. BOARD, circuit	1	404	15B292	COVER	1
401b	246478	. SWITCH, membrane	1	405	15B291	PLATE	1
401c	112324	. SCREW	4	406	246287	HARNESS, wire, red stop button	1
402	245977	DISPLAY, temperature; includes 402a-402c	1	407	117499	HANDLE	2
402a	246130	. BOARD, circuit	1	408	117523	NUT, cap; 10-24	8
402b	246479	. SWITCH, membrane	1	410	111393	SCREW, machine, pan-hd; M5 x 0.8; 16 mm	4
402c	112324	. SCREW	4	411	15B386	CABLE, display	1
				412	195853	SCREW, machine; M2.5 x 6	2

# Temperature Control

## 245979 Temperature Control

 Apply 110009 thermal heatsink compound to mating surfaces.




TI2575A-1


Ref. No.	Part No.	Description	Qty
501	15B779	HEAT SINK	1
502	246194	BOARD, temperature control	1
503	117683	SCREW, 6-32 x 1-1/2 in. (38 mm)	2
504	117526	SPACER	5
505	104590	SCREW, machine; 6-32 x 3/8 in. (10 mm)	5

# Motor Control

## 245980 Motor Control, for E-20 and E-XP1



TI3153A


 Apply 110009 thermal heatsink compound to mating surfaces.

Ref. No.	Part No.	Description	Qty
601	15B297	HEAT SINK	1
602	246195	BOARD, motor control	1
603	107156	SCREW, machine; 6-32	7

## 245981 Motor Control, for E-30 and E-XP2

⚠️ 1 Apply 110009 thermal heatsink compound to mating surfaces.

⚠️ 2 Motor harness (609) plugs in here.




TI2576A

Ref. No.	Part No.	Description	Qty
601	15B297	HEAT SINK	1
602	246196	BOARD, motor control	1
603	104590	SCREW, machine; 6-32 x 3/8 in. (10 mm)	6
604	117526	SPACER	3
605	117683	SCREW, 6-32 x 1-1/2 in. (38 mm)	2
607	15C007	INDUCTOR	1
609	15B408	CABLE, harness, motor	1

# Fluid Manifold

## 246154 Fluid Manifold

- ① Apply 113500 thread lock (blue).
- ② Torque to 355-395 in-lb (40.1-44.6 N•m).
- ③ Apply PTFE tape or thread sealant to tapered threads.
- ④ Torque to 175-195 in-lb (19.8-22.0 N•m).
- ⑤ Lubricate ends of spring when assembling.
- ⑥ Assemble valves (702) and handles (709) with handles facing away from each other.
- ⑦ Assemble seat (707) with lapped seat facing valve (702).
- ⑧ Apply grease (118665) to seat (707) and seal (708) prior to inserting into valve (702) to aid retention during assembly to manifold (701).



TI2573A

Ref. No.	Part No.	Description
701	15B332	MANIFOLD; aluminum
702*	246161	VALVE, pressure relief/spray
704	102814	GAUGE; 5000 psi (35 MPa, 350 bar)
705	162453	NIPPLE; 1/4 npt x 1/4 npsm
706	246123	TRANSDUCER, pressure control
707*	193709	SEAT, valve; carbide
708*	193710	SEAL, seat; nylon
709*	15B287	HANDLE, valve
710*	114708	SPRING
711*	117623	NUT, cap; 3/8-16
714	117556	ELBOW, 45°; #8 JIC x 1/2 npt


Qty	Ref. No.	Part No.	Description	Qty
1	715	117557	ELBOW, 45°; #10 JIC x 1/2 npt	1
2	716	117532	ELBOW; 1/2 npt(m) x 1/2 in. (13 mm) OD tube	2
2	718	100840	ELBOW, street; 1/4 npsm x 1/4 npt	2
2	720	111457	O-RING; PTFE	2
2	721▲	189285	LABEL, caution	1

\* Included in Repair Kit 246842 (purchase separately).

▲ Replacement Warning labels, signs, tags, and cards are available at no cost.


# Circuit Breaker Modules

## 230V, 3 Phase Circuit Breaker Modules

 For wiring and cable connections, refer to electrical diagrams supplied. See page 67 for parts list.


### Part No. 246087 (E-20, E-30, E-XP1)

\* Ref. No. 92 not included with module.  
Order separately, see page 52.



### Part No. 246089 (E-XP2)


\* Ref. No. 92 not included with module.  
Order separately, see page 52.








### 380V, 3 Phase Circuit Breaker Modules

 For wiring and cable connections, refer to electrical diagrams supplied. See page 67 for parts list.


#### Part No. 246096 (E-20, E-30, E-XP1)

\* Ref. No. 92 not included with module.  
Order separately, see page 52.



#### Part No. 246098 (E-XP2)

\* Ref. No. 92 not included with module.  
Order separately, see page 52.



## Circuit Breaker Modules Parts List


Ref. No.	Description	Breaker Modules									Qty
		246087 230V, 3 $\theta$	246087 230V, 3 $\theta$ (E-30 only)	246089 230V, 3 $\theta$	246090 230V, 1 $\theta$	246090 230V, 1 $\theta$ (E-30 only)	246092 230V, 1 $\theta$	246096 380V, 3 $\theta$	246096 380V, 3 $\theta$ (E-30 only)	246098 380V, 3 $\theta$	
801	RAIL, mounting	buy locally	buy locally	buy locally	buy locally	buy locally	buy locally	buy locally	buy locally	buy locally	1
802	CLAMP, end	112446	112446	112446	112446	112446	112446	112446	112446	112446	3
803	TERMINAL, base, fuse plug	117798	117798	117798	117798	117798	117798	117798	117798	117798	2
804	BREAKER, dual; 25A	117591	117591		117591	117591		117591	117591		2
	BREAKER, dual; 40A			117505			117505			117505	2
805	BAR, power buss, 3 $\theta$	117805	117805	117805							1
	BAR, power buss, 1 $\theta$				117678	117678	117678				1
806	BREAKER, single; 50A	117503	117503	117503	117503	117503	117503	117503	117503	117503	1
807	CONNECTOR, power lug	117679	117679	117679							3
	CONNECTOR, power lug				117679	117679	117679				2
808	CABLE, harness; 230V, 3 $\theta$	15B387	15B387	15B387							1
	CABLE, harness; 230V, 1 $\theta$				117674	117674	117674				1
	CABLE, harness; 380V, 3 $\theta$							15B377	15B377	15B377	1
809	TERMINAL, block	117796	117796	117796	117796	117796	117796	117796	117796	117796	2
810	CABLE, harness, power temp	15B375	15B375	15B375	15B375	15B375	15B375	15B375	15B375	15B375	1
811	CABLE, hose, heat	15B378	15B378	15B378	15B378	15B378	15B378	15B378	15B378	15B378	1
813	BLOCK, terminal ground	112443	112443	112443	112443	112443	112443	112443	112443	112443	1
814	FUSE, fan; 5 x 20 mm Bussman GDA-2A or equivalent	115216	115216	115216	115216	115216	115216	115216	115216	115216	2
815	TERMINAL, end cover	117807	117807	117807	117807	117807	117807	117807	117807	117807	1
816	CABLE, harness, heat A/B	15B376	15B376	15B376	15B376	15B376	15B376	15B376	15B376	15B376	2
817	BREAKER, dual; 20A	117711	117711	117711	117711	117711	117711	117711	117711	117711	2
818	TERMINAL, end cover	117797	117797	117797	117797	117797	117797	117797	117797	117797	1
819	FUSE, plug	117799	117799	117799	117799	117799	117799	117799	117799	117799	2

\* Not included with module. Order separately.

## 248669 Conversion Kit

Convert and phase E-XP2 to an E-30 with 15.3kW of heat by changing pump lowers, bearings, and changing the Motor Control DIP settings to that of an E-30. For removal and installation of pump lowers and bearings, see **Pump Removal**, page 20. For changing Motor Control DIP settings, see **Motor Control Board**, page 30.

Ref. No.	Part No.	Description	Qty
65	118463	ELBOW, swivel; 3/4 npt(m) x 1 in. npt(f)	2
303	245927	HOUSING, bearing	2
306A	246832	PUMP, displacement, component A; see 309557	1
306B	245972	PUMP, displacement, component B; see 309577	1
316	193394	NUT, retaining	2



# Technical Data

Category	Data
Maximum Fluid Working Pressure	Models E-20 and E-30: 2000 psi (14 MPa, 140 bar) Model E-XP1: 2500 psi (17.2 MPa, 172 bar) Model E-XP2: 3500 psi (24.1 MPa, 241 bar)
Maximum Fluid Temperature	190°F (88°C)
Maximum Output	Model E-20: 20 lb/min (9 kg/min) Model E-30: 30 lb/min (13.5 kg/min) Model E-XP1: 1 gpm (3.8 liter/min) Model E-XP2: 2 gpm (7.6 liter/min)
Output per Cycle (A and B)	Model E-20 and E-XP1: .0104 gal. (.0395 liter) Model E-30: .0272 gal. (0.1034 liter) Model E-XP2: .0203 gal. (.0771 liter)
Line Voltage Requirement	Part Nos. 246024, 246025, 246026, 246028, 248657: 195-264 Vac, 50/60 Hz Part Nos. 246029, 246030, 246031, 246032, 248659: 338-457 Vac, 50/60 Hz Part Nos. 246033, 246034, 246035, 246036, 248658: 195-264 Vac, 50/60 Hz
Amperage Requirement	See page 3.
Heater Power	Model E-20: 6000 Watts Model E-30 and E-XP1: 10200 Watts Models E-XP2 and E-30 with 15.3kW of heat: 15300 Watts
Sound Power, per ISO 9614-2	Model E-20: 80 dB(A) at 2000 psi (14 MPa, 140 bar), 0.5 gpm (1.9 lpm) Model E-30: 93.5 dB(A) at 1000 psi (7 MPa, 70 bar), 3.0 gpm (11.4 lpm) Model E-XP1: 80 dB(A) at 2000 psi (14 MPa, 140 bar), 0.5 gpm (1.9 lpm) Model E-XP2: 83.5 dB(A) at 3000 psi (21 MPa, 210 bar), 1.0 gpm (3.8 lpm)
Sound Pressure, 1 m from equipment	Model E-20: 70.2 dB(A) at 2000 psi (14 MPa, 140 bar), 0.5 gpm (1.9 lpm) Model E-30: 83.6 dB(A) at 1000 psi (7 MPa, 70 bar), 3.0 gpm (11.4 lpm) Model E-XP1: 70.2 dB(A) at 2000 psi (14 MPa, 140 bar), 0.5 gpm (1.9 lpm) Model E-XP2: 73.6 dB(A) at 3000 psi (21 MPa, 210 bar), 1.0 gpm (3.8 lpm)
Fluid Inlets	3/4 npt(f), with 3/4 npsm(f) union
Fluid Outlets	Component A (ISO): #8 JIC (3/4-16 unf), with #5 JIC adapter Component B (RES): #10 JIC (7/8-14 unf), with #6 JIC adapter
Fluid Circulation Ports	1/4 npsm(m), with plastic tubing
Weight	Model E-20 and E-XP1: 342 lb (155 kg) Model E-30: 400 lb (181 kg) Models E-XP2 and E-30 with 15.3kW of heat: 438 lb (198 kg)
Wetted Parts	Aluminum, stainless steel, carbon steel, brass, carbide, chrome, chemically resistant o-rings, PTFE, ultra-high molecular weight polyethylene

Loctite® is a registered trademark of the Loctite Corporation.

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**TO PLACE AN ORDER**, contact your Graco distributor, or call this number to identify the distributor closest to you:

**1-800-328-0211 Toll Free**

**612-623-6921**

**612-378-3505 Fax**

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

MM 309574

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

www.graco.com

309574J 6/2006