

GX-8P Spray Gun


<u>3</u>11338 rev. A


For use with non-flammable polyurethane foams, two-component coating systems (polyureas), and some two-component epoxy systems. Not for use in explosive atmospheres.

3500 psi (24 MPa, 240 bar) Maximum Working Pressure 125 psi (90 KPa, 9 bar) Maximum Air Working Pressure



Important Safety Instructions Read all warnings and instructions in this manual. Save these instructions.





PROVEN QUALITY. LEADING TECHNOLOGY.

Contents

Warnings
Overall View 5
Centerline Components5
Mixing Module 6
Operation Basics7
Isocyanate Hazard7
Keep A and B Components Separate7
Grounding 7
Safety Position7
Air Hose Connection
Coupling Block 8
Air Inlet Configuration
Mixing Module and PCD Installation
Valving Rod Adjustment
Initial Set Up 12
Daily Start-up13
Daily Shutdown 13
Pressure Relief Procedure 14
Maintenance 15
Gun Service Kits 15
Clean Spray Gun Procedure
Flush Gun

Repair
Service Screen Screw17
Remove Check Valve17
Remove Centerline Components
Install Centerline Components
Replace End Cap and Air Piston Assembly 19
Replace Trigger Valve O-Rings
Clean Mixing Module23
Parts
GX-8 Gun Final Assembly (297678)24
GX-8 Handle Assembly (297702)26
GX-8P Spray Gun Final Assembly (297860) 28
GX-8P Auto Cylinder Assembly (297861) 30
Auto GX-8P Optional Parts
Coupling Block Assembly (295383)
Coupling Block Assembly (260810)
Set-up Chart for GX-8P Modules
GX-8P Model Specifications
Tool Kits
Technical Data 37
Notes
Graco Standard Warranty
Graco Information40

Warnings

The following general warnings are for the setup, use, grounding, maintenance, and repair of this equipment. Additional, more specific warnings may be found throughout the body of this manual where applicable. Symbols appearing in the body of the manual refer to these general warnings. When these symbols appear throughout the manual, refer back to these pages for a description of the specific hazard.

	 PERSONAL PROTECTIVE EQUIPMENT You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, inhalation of toxic fumes, burns, and hearing loss. This equipment includes but is not limited to: Protective eyewear Clothing and respirator as recommended by the fluid and solvent manufacturer Gloves Hearing protection
*	 TOXIC FLUID OR FUMES HAZARD Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed. Read MSDS's to know the specific hazards of the fluids you are using. Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.
	 SKIN INJECTION HAZARD High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment. Do not point gun at anyone or at any part of the body. Do not put your hand over the spray tip. Do not stop or deflect leaks with your hand, body, glove, or rag. Do not spray without tip guard and trigger guard installed. Engage trigger lock when not spraying. Follow Pressure Relief Procedure in this manual, when you stop spraying and before cleaning, checking, or servicing equipment.
NP-aburP3	 PRESSURIZED EQUIPMENT HAZARD Fluid from the gun/dispense valve, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury. Follow Pressure Relief Procedure in this manual, when you stop spraying and before cleaning, checking, or servicing equipment. Tighten all fluid connections before operating the equipment. Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.

 FIRE AND EXPLOSION HAZARD Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion: Use equipment only in well ventilated area. Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). Keep work area free of debris, including solvent, rags and gasoline. Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present. Ground all equipment in the work area. See Grounding instructions. Use only grounded hoses. Hold gun firmly to side of grounded pail when triggering into pail. If there is static sparking or you feel a shock, stop operation immediately. Do not use equipment until you identify and correct the problem.
 EQUIPMENT MISUSE HAZARD Misuse can cause death or serious injury. Do not operate the unit when fatigued or under the influence of drugs or alcohol. Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Data in all equipment manuals. Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS forms from distributor or retailer. Check equipment daily. Repair or replace worn or damaged parts immediately with genuine Graco/Gusmer replacement parts only. Do not alter or modify equipment. Use equipment only for its intended purpose. Call your Graco/Gusmer distributor for information. Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not kink or over bend hoses or use hoses to pull equipment. Keep children and animals away from work area. Comply with all applicable safety regulations.
PRESSURIZED ALUMINUM PARTS HAZARD Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in pressurized aluminum equipment. Such use can cause serious chemical reaction and equipment rupture, and result in death, serious injury, and prop- erty damage.

Overall View





FIG. 2: GX-8P Centerline Components

Mixing Module

Graco offers a variety of spray tip configurations to meet most applications that spray fast-reaction chemical systems at low outputs. GX-8P spray tip components consist of a Pattern Control Disc (PCD) and a Mixing Module (Figure 3). Tip components are available in a range of sizes in both round and fan spray patterns. Please contact your authorized Graco distributor to help you determine the best configurations for your specific application.



Operation Basics



To prevent accidental gun operation, always disconnect air supply before servicing gun or anytime gun is not in use.

Isocyanate Hazard



Read Material Safety Data Sheet (MSDS) to know specific hazards of isocyanates. Use equipment in a well-ventilated area. Wear respirator, gloves, and protective clothing when isocyanates are used.

Keep A and B Components Separate

CAUTION

To prevent cross-contamination of gun's wetted parts, do not interchange A component (isocyanate) and B component (resin) parts. Gun is shipped with A side on left.

Grounding



Check your local electrical code and proportioner manual for detailed grounding instructions.

Ground spray gun through connection to Graco-approved grounded fluid supply hose.

Safety Position

GX-8P guns have a two-position safety stop. When engaged, it prevents accidental triggering of gun during servicing or down time. When disengaged, it allows gun to dispense.

Engage Safety Stop

To engage safety stop, push in and turn safety stop clockwise to place gun in CLOSED safety position.




FIG. 4: Safety Stop - Engaged

Disengage Safety Stop

To disengage safety stop, push in and turn safety stop counterclockwise to place gun in OPEN position.




FIG. 5: Safety Stop - Disengaged

Air Hose Connection



Connect Air Hoses

Pull back sleeve of female fitting, insert male fitting and slide sleeve forward to secure connection.

Disconnect Air Hoses

Pull back sleeve of female fitting and pull out male fitting.




FIG. 6: Disconnect Air Hose

Coupling Block

Chemical hoses are joined to gun block by a coupling block to ease installation and removal of gun.

Manual Valves

Two manual valves located on coupling block control flow of each chemical component to gun.

Triggering gun with manual valves closed may cause crossover if any residual chemical remains in gun ports.



Never open manual valve unless coupling block is secured to gun or unless you point gun into waste container.

Open Manual Valves

Use 5/16 in. nut driver to turn manual valve clockwise approximately three full turns.




FIG. 7: Open Manual Valves

Close Manual Valves

Use 5/16 in. nut driver to turn manual valve fully counterclockwise.

CAUTION

To prevent accidental gun operation, always set safety stop to CLOSED, close both manual valves, and disconnect air supply.

Installation and Removal



To prevent release of pressurized chemicals, close both manual valves before coupling block is removed.

Install Coupling Block

- 1. Replace nicked, damaged, or worn coupling block gaskets.
- 2. Ensure A-(isocyanate) and B-(resin) check valves are inserted into their proper recesses in gun block. Isocyanate valve is notched for easy identification.

3. Fit coupling block into gun block and insert coupling block mounting screw. Use 5/16 in. nut driver to tighten to gun block.




FIG. 8: Install Coupling Block

Remove Coupling Block

- 1. CLOSE safety stop.
- 2. Disconnect air hose.
- 3. Close both manual valves.
- 4. Remove coupling block mounting screw.
- 5. Separate coupling block from gun.
- 6. Wipe mating surfaces of gun block and coupling block to remove residual chemicals.
- 7. Cover exposed openings with grease.

To avoid accidental gun operation, ensure coupling block manual valves are closed before attempting to service gun, or any time gun is not in use.

Air Inlet Configuration

There are two configurations for the air inlet. In the standard configuration, the air inlet is at base of handle. In the alternate configuration, the air inlet is at rear of gun.




FIG. 9: Air Inlet Configuration

To change to alternate configuration:

- 1. Use 6 in. adjustable wrench to remove 4 in. pipe nipple from base of gun.
- 2. Use 3/16 in. hex key to remove 1/8 in. pipe plug from rear of gun.
- 3. Use 3/16 in. hex key to install 1/8 in. pipe plug in location previously occupied by 4 in. pipe nipple.
- 4. Use 6 in. adjustable wrench to install pipe nipple in location previously occupied by 1/8 in. pipe plug.

Mixing Module and PCD Installation

- 1. Loosen air cap by hand and remove.
- 2. Install mixing module:
 - a. Disconnect gun from coupling block.
 - b. Connect air supply to gun.
 - c. Set safety stop to OPEN.
 - d. Hold down trigger and place module over tip of valving rod.
 - e. Align keying pin with slot in gun block and keep gun trigger held down.
- 3. Install PCD:
 - a. Hold down gun trigger and thread PCD retainer in place by hand.
 - b. Use 10 in. adjustable wrench to carefully tighten PCD retainer until snug enough to ensure no leak will occur.
 - c. Release gun trigger.
- 4. Install air cap and tighten by hand.
- 5. Adjust valving rod (see **Valving Rod Adjustment**, page 11).

Valving Rod Adjustment

Valving rod should not require adjustment if it was shipped from factory with mixing module and PCD installed. Valving rod should only require adjustment when:

- Piston/rod assembly/ring is changed
- Valving rod is changed
- PCD is installed or changed
- Mixing module is installed or changed

To adjust valving rod:

- 1. Perform Clean Spray Gun Procedure, (see page 15.
- 2. Connect air supply to gun.
- 3. Use 5/16 in. open-end wrench to loosen packing nut 3 or 4 turns. This relieves pressure between seals and makes adjustment easier.




FIG. 10: Valving Rod Adjustments

- Use 3/8 in. wrench on hex-shaped valving rod shank and 1/2 in. wrench on jam nut to loosen and back it away from valving rod by 3 or 4 full turns. Then move valving rod toward gun cylinder. Turn valving rod shank 2 or 3 full turns clockwise.
- Slowly turn valving rod counterclockwise to move it toward PCD until resistance is felt. Valving rod tip should touch inside spherical surface of PCD.
- 6. Carefully maintain 3/8 in. wrench in position and tighten jam nut up against valving rod shank to lock adjustment into place.
- 7. Retighten packing nut.
- Check rear safety stop by attempting to disengage it. If knob will not turn, valving rod is adjusted too far forward. Repeat steps 3 -7. Make sure not to adjust valving rod past the point resistance is felt. If safety stop disengages, proceed to step 9.
- Trigger gun with safety stop disengaged to confirm rear seal adjustment. Make sure rod moves freely. If not, loosen packing nut slightly until it does. Start to spray and check for chemical seepage from packing nut and retighten if necessary.
 - If valving rod required adjustment as part of initial mixing module and PCD installation on a new spray gun, proceed to **Initial Set Up**, page 12.

Initial Set Up



- 1. Remove coupling block from gun.
- 2. Use two 6 in. adjustable wrenches to install female quick disconnect fitting onto air supply hose bundled with chemical supply hoses.
- Use two 6 in. adjustable wrenches to connect A-isocyanate hose (red-taped) to notched fitting on coupling block. Connect B-resin hose (blue-taped) to fitting without notches on coupling block.
- 4. Close both manual valves.
- 5. Pressurize A and B chemical hoses and check for leaks (see Proportioner manual as needed).

- 6. Bleed air from chemical hoses:
 - a. Hold coupling block with exit ports pointed into waste container.
 - b. Use 5/16 in. nut driver to open each manual valve; this allows any trapped air to escape. Bleed each side for a short time until chemicals leaving hoses are free of air.
 - c. Close both manual valves.
- 7. Use cloth soaked in gun cleaner to clean coupling block and mating surfaces.

CAUTION

Do not apply grease to mating surfaces of coupling block to avoid accumulation of dirt and other contaminants.

- 8. CLOSE safety stop.
- 9. Install coupling block to gun.
- 10. Proceed with daily start-up and shutdown procedures as required.


Daily Start-up



Ensure gun is attached to coupling block and air hose. Ensure proportioning unit is at desired temperature and pressure. Properly ground equipment to avoid static sparking that may result in fire or explosion.

- 1. Connect air supply to gun.
- 2. Adjust air cap adjustment valve. Turn knob counterclockwise to open valve and clockwise to close valve.
- 3. Open both manual valves.
- 4. OPEN safety stop.
- 5. Test spray on a disposable surface and evaluate.

Daily Shutdown



- Follow daily shutdown procedure when gun is out of service for any length of time, or for mid- or end-of-day service. See **Clean Spray Gun Procedure**, page 15.
- 1. CLOSE safety stop.
- 2. Close both manual valves.
- 3. Disconnect air supply from gun.
- 4. Shut down proportioning unit as required.
- 5. Clean as required (see Clean Spray Gun Procedure, page 15).
 - Disassembling gun for daily cleaning is not recommended if gun has been operating properly. However, if gun is removed from coupling block, it must be flushed and cleaned thoroughly.

Pressure Relief Procedure



Relieve pressure before cleaning or repairing gun.

1. Close both manual valves.




FIG. 11: Close Manual Valves

- 2. OPEN safety stop.
- 3. Trigger gun onto cardboard or into waste container to relieve pressure.




FIG. 12: Trigger Gun

4. Release gun trigger, CLOSE safety stop, and close manual valves.



If fluid in hose and proportioner is still under pressure, follow Pressure Relief Procedure in proportioner manual

To relieve pressure in hose after gun is removed, place fluid manifold over containers, facing away from you. Very carefully open fluid valves (FIG. 13). Under high pressure, fluid will spray sideways from fluid ports.




FIG. 13: Open Manual Valves

Maintenance

Gun Service Kits

Use either 1-Quart Gun Service Kit (296980) or 3-Gallon Gun Service Kit (296981) to perform daily flushing of spray gun without disassembly.




FIG. 14: 1-Quart Gun Service Kit

For more information about 1-Quart Gun Service Kit, see Manual 311340.




FIG. 15: 3-Gallon Gun Service Kit

For more information about 3-Gallon Gun Service Kit, see Manual 311341.

Clean Spray Gun Procedure



To avoid static sparking that may result in fire or explosion, ensure all equipment in cleaning procedure is grounded. Do not clean on or near foamed or coated surfaces or any other flammable surfaces or objects.

Thoroughly flush gun block with gun cleaner before removing valving rod or mixing components from gun block. Also allow chemicals in spray gun to cool before cleaning.

This procedure makes use of the 1-Quart or 3-Gallon Gun Service Kit.

- 1. CLOSE safety stop.
- 2. Close both manual valves.
- 3. Remove gun from coupling block.

- 4. Attach service block of gun service kit to spray gun, and then tighten using 5/16 in. nut driver.
- 5. Pressurize service kit container up to 100 psi. DO NOT EXCEED 100 psi (0.7 MPa, 7 bar).
- 6. Clean gun:
 - a. Set safety stop to OPEN.
 - b. Open either manual valve on service block.
 - c. Trigger gun and gun service kit simultaneously with gun aimed into waste container.
 - d. Release both triggers and close manual valves on service block.
 - e. Repeat procedure for other side of gun.
 - f. After initial cleaning, remove air cap, PCD retainer, and PCD. Flush a second time to ensure thorough cleaning.
- 7. CLOSE safety stop.
- 8. Disconnect air supply from gun.
- 9. Remove service block of gun service kit from gun.

- 10. Clean screens, check valves and screen screw (see **Service Screen Screw**, page 17.
 - Inspect air cap, PCD, mixing module, and gun block for build up of material and clean as required.

Do not use metal cleaning devices to clean plastic components.

Flush Gun



To avoid static sparking that may result in fire or explosion, ensure all equipment in flushing procedure is grounded. Do not flush on or near foamed or coated surfaces.


- 1. CLOSE safety stop.
- 2. Close both manual valves.
- 3. Loosen B-Screen screw and then remove by hand.
- 4. Use flush can to thoroughly flush screen screw and screen screw cavity.
- 5. Loosen A-Screen screw and then remove by hand.
- 6. Use flush can to thoroughly flush screen screw and screen screw cavity.
- 7. Service gun, see **Maintenance** procedures, page 15.

Repair




Shutdown proportioner and allow chemicals to cool before servicing gun.

Service Screen Screw



To avoid static sparking that may result in fire or explosion, ensure all equipment in flushing procedure is grounded. Do not flush on or near foamed or coated surfaces.

- 1. Flush gun see Clean Spray Gun Procedure, page 15.
- 2. Unthread screen screw from gun block.
- 3. Remove screen screw retainer before removing screen.
- 4. Remove screen from screen screw. Soak in gun cleaner or replace if clogged or dirty.
- 5. Clean screen screw cavity. If **any** particles are visible, clean with clean out drills and flush with gun cleaner.



- 6. Inspect screen screw seal for damage. Replace if necessary.
- 7. Reinstall screen screw in gun block. Ensure it is tight.
- 8. Flush gun with mixing module removed.

Remove Check Valve

To avoid static sparking that may result in fire or explosion, ensure all equipment in flushing procedure is grounded. Do not flush on or near foamed or coated surfaces.

Check valves are located in cavities of gun block under each coupling block gasket. Check valves are triangular pieces with a spring inserted in one end. The isocyanate valve is notched for easy identification.

To remove check valve:

- 1. Clean gun (see Clean Spray Gun Procedure, page 15).
- Use check valve seal removal/cleaning tool to remove gaskets from recesses in coupling block. Inspect gaskets for damage and replace if necessary.
- Remove check valves. If valve does not come out easily, insert machined end of removal/cleaning tool over valve and rotate it while extracting valve.
- 4. Clean valves and springs with gun cleaner. Inspect for damage and replace if necessary.
- 5. Inspect each check valve cavity. Use cleaning tool to remove any visible particles. Use gun cleaner to flush thoroughly.
- Insert each check valve into its cavity spring end first. Ensure check valve is oriented correctly. Isocyanate valve is notched for easy identification.
- 7. Install coupling block gaskets.

Remove Centerline Components

Refer to page 5 for diagrams of centerline components for all gun models.

- 1. Flush gun (see Clean Spray Gun Procedure, page 15).
- 2. Remove air cap (loosen by hand).
- 3. Use 10 in. adjustable wrench to remove PCD.
- 4. Connect air supply to gun.
- 5. Lift PCD off nose of gun block and remove.
 - To remove PCD that is stuck, set safety stop to OPEN, depress and release gun trigger to unseat it. CLOSE safety stop.
- 6. Remove mixing module retainer.
- 7. OPEN safety stop. Depress and release gun trigger to unseat it. Remove mixing module off end of valving rod. CLOSE safety stop.

CAUTION

Do not use sharp objects or metal tools to remove mixing module.

- 8. Disconnect air supply from gun.
- 9. Use 5/16 in. wrench to loosen packing nut 3 or 4 turns.
- 10. Remove gun block:
 - a. Use 5/16 in. nut driver to remove gun block retaining screw.
 - b. Slide gun block away from valving rod and air cylinder. If dried chemical is built

up on gun block, remove dried chemicals to make removal easier.

- 11. Remove and clean check valves (see **Remove Check Valve**, page 17).
- 12. Remove valving rod:
 - a. Use 3/8 in. wrench on hex-shaped valving rod shank and a 1/2 in. wrench on jam nut to loosen it and back it away from valving rod shank by 3 or 4 full turns.
 - b. Unthread valving rod from piston shaft and remove.
- 13. Clean all components thoroughly before reassembly.
- 14. Inspect gun block to ensure proper operation of spray gun.

Install Centerline Components

Before installation, ensure all gun components are clean and dry. Lubricate all moving parts and threads.

- 1. To install valving rod, thread jam nut as far back on piston shaft as possible. Screw shank end of valving rod onto threaded end of piston rod.
- 2. Install rear seal and packing nut if removed. Thread packing nut into gun block by hand, but do not tighten.
- To install gun block, carefully slide gun block onto valving rod towards air cylinder. Use 5/16 in. nut driver to install gun block onto gun block mounting bracket.
- 4. Connect air supply to gun.

- 5. OPEN safety stop.
- To install mixing module, hold down gun trigger and slide module over end of valving rod. Make sure to align keypin with slot in gun block. Keep gun trigger depressed and proceed to step 7.
- To install PCD, hold gun trigger in and place PCD over mixing module. If installing a fan tip, position PCD according to which spray direction is needed (vertical or horizontal). Keep gun trigger depressed and proceed to step 8.

Parts must align properly or chemical flow from gun block ports will not enter mixing module when gun is triggered.

- 8. Install PCD retainer:
 - a. With gun trigger depressed, thread PCD retainer in place by hand.
 - b. Use 10 in. adjustable wrench to carefully tighten PCD retainer until it is snug enough to ensure no leak will occur.
 - c. Release gun trigger.

CAUTION

To avoid damage to module and gun block, do not overtighten mixing module retainer.

- 9. Install air cap and tighten by hand.
- 10. Adjust valving rod (see Valving Rod Adjustment, page 11).

Replace End Cap and Air Piston Assembly




FIG. 16: End Cap and Air Piston Assembly

- 1. Clean gun (see Clean Spray Gun Procedure on page 15).
- 2. Disconnect air supply from gun.
- Use 5/16 in. wrench to loosen packing nut 3 or 4 turns (remove nut completely if rear seal needs to be replaced).
- 4. Remove gun block:
 - a. Use 5/16 in. nut driver to remove gun block mounting screw.
 - b. Carefully slide gun block away from valving rod and air cylinder. If dried chemical has built up on gun block, remove dried chemical to make removal easier.
 - c. Remove valving rod and jam nut (see **Remove Check Valve**, page 17):

- d. Use 3/8 in. wrench on hex-shaped valving rod shank and 1/2 in. wrench on jam nut.
- e. Loosen jam nut and back it away from valving rod shank by 3 or 4 full turns.
- f. Unthread valving rod and jam nut from piston shaft.
- 5. OPEN safety stop.
- 6. Use 9/64 in. ball point hex key to remove socket head cap screw that holds air cylinder to handle (FIG. 16).
- 7. Use retaining ring 45° pliers to remove retaining ring that holds end cap in place inside air cylinder.
- 8. Remove end cap/safety stop assembly and piston spring:
 - a. Pull safety stop and attached end cap out of air cylinder.
 - b. Remove piston spring located inside cylinder. Be sure to retain spring for reinstallation.

Force will be required to remove end cap because ring is tightly compressed.

- 9. Inspect end cap ring. Replace if damaged. Apply light coating of Lubriplate grease and install new end cap ring.
 - Skip steps 11-13 and go to step 14 if only end cap ring and cup seal need to be replaced.

- Remove piston/rod assembly:
 Use gun block mounting screw (screw that holds gun block to bracket) to aid in removal of piston.
- b. Look into rear of air cylinder and thread mounting screw into center hole of piston at least 4 full turns.
- c. Use 6 in. pliers to grab mounting screw and pull piston rod assembly out of air cylinder.
- d. Inspect ring and replace if damaged. Apply light coat of Lubriplate grease and install new ring.
- 10. Inspect air cylinder cup seal. If air escapes around piston rod during operation, remove and replace cup seal located in front of air cylinder. Lubricate new cup seal with Lubriplate grease and install it. Make sure cup faces toward rear of cylinder.
- 11. Insert piston and rod assembly into air cylinder. Be careful not to damage cup seal in front face of air cylinder as rod passed though. Remove gun block mounting screw from piston.
- 12. Disassemble safety stop mechanism:
 - a. Use 5/64 in. hex key to remove two set screws from knob.
 - b. Slide knob off stop pin and retain stop pin spring.
 - c. Pull shaft out of end cap (FIG. 17).
- 13. Remove cup seal from end cap and inspect for damage. Remove if damaged. Apply light coat of Lubriplate grease and install new end cap ring.




FIG. 17: End Cap/Safety Stop Assembly

- 14. Reassemble safety stop mechanism:
 - a. Insert stop pin into end cap hole.
 - b. Slide spring and knob onto stop pin.
 - Use 5/64 in. hex key to reinstall two set screws into knob. Ensure knob is secure.
- 15. Reinstall end cap/safety assembly and piston spring:
 - a. Insert piston spring and align over raised center of piston.
 - Line up raised center of end cap with spring and insert end cap into air cylinder.
 - c. Press end cap until it moves past retaining ring groove in cylinder.
 - d. Maintain pressure on end cap. Ensure groove remains visible.
- 16. Use retaining ring 45° pliers to reinstall retaining ring into groove .

Retaining rin	na mus	t seat o	comple	telv int	0

groove to secure end cap in place when air cylinder is pressurized. Keep clear of cap when air pressure is applied or gun is triggered after reassembly.

- 17. Use 9/64 in. ball-point hex key to install and tighten socket head cap screw, which holds air cylinder to handle.
- 18. Reinstall valving rod and jam nut:
 - a. Thread jam nut as far as it will go onto threaded end of piston shaft.
 - b. Ensure hex end of nut faces rear.
 - c. Thread valving rod as far onto threaded portion of piston rod as possible.
- 19. Thread packing nut into gun block by hand but do not tighten.
- 20. Install gun block:
 - a. Ensure ring is in place in top of gun block.
 - b. Carefully slide gun block onto valving rod toward air cylinder.
 - c. Use 5/16 in. nut driver to install gun block onto gun block mounting bracket.
- 21. Adjust valving rod (see Valving Rod Adjustment on page 11).

Replace Trigger Valve O-Rings

- 1. Clean gun (see Clean Spray Gun Procedure, page 15).
- Perform Pressure Relief Procedure, page 14.
- Disconnect air supply from gun. Refer to **Parts**, page 24.




FIG. 18: Replace Trigger Valve O-Ring

- 4. Use 6 in. adjustable wrench and 6 in. pliers to remove screw and locknut that hold trigger lever in place. Remove trigger lever.
- 5. Use 3/8 in. wrench to loosen and remove valve retainer nut.
- 6. Remove valve spool and spring:
 - a. Grab end of spool and pull out. Spring will come out with spool. **Do not** lose spring--it belongs in hole at end of spool.
 - b. Remove old rings.

- c. Apply thin coat of Lubriplate grease to new rings and reinstall.
- Follow steps 6-14 to replace rings on valve liner. If rings do not need to be replaced, proceed to step 15.
- 7. Use 3/16 in. hex key to remove 1/8 in. rear internal plug. This plug seals another air-flow path in gun handle.
 - For guns configured with air inlet at rear of gun handle, pipe nipple replaces pipe plug. Remove pipe nipple.
- 8. Use 5/32 in. hex key to remove rear internal pipe plug (under pipe plug).
- 9. Use pin punch and hammer to gently tap spring seat until it and valve liner push out opposite end of hole.
- 10. Remove rings on liner. Apply thin coat of Lubriplate grease to new rings and install.
- 11. Clean valve hole. Remove any dirt and debris. Apply thin coat of Lubriplate grease to inside of valve hole.
- 12. Slide spring seat into gun handle air valve hole, tapered end first, until it bottoms out.
- 13. Push valve liner in as far as it will go. Install valve retainer nut, it will align valve liner and spool to their proper depth.
- 14. Use 5/32 in. hex key to screw 1/16 in. pipe plug back into place. Apply think coat of pipe thread sealant to threads prior to insertion to help prevent air leaks.
- 15. Apply small amount of pipe thread sealant to 1/8 in. plug threads. Screw pipe plug in place.
- 16. Insert valve spool into valve liner with valve spool spring still in place. Screw in valve retainer nut; tighten until snug.

17. Use screw and locknut to reinstall trigger lever.

Clean Mixing Module

- 1. Flush gun (see Clean Spray Gun Procedure, page 15).
- 2. Connect air supply to gun. OPEN safety stop.
- 3. Remove air cap by hand.




FIG. 19: Unthread Cap from PCD Body

- 4. Trigger gun and hold it to relieve pressure on PCD retainer.
- 5. Turn PCD retainer counterclockwise and remove.
- 6. Remove PCD from mixing module retainer.
- To remove PCD that is stuck, set safety stop to OPEN, depress and release gun trigger to unseat it. CLOSE safety stop.
- 7. Remove mixing module retainer.
- 8. OPEN safety stop. Depress and release gun trigger to unseat it. Remove mixing

module from end of valving rod. CLOSE safety stop.

- 9. Inspect valving rod for damage and replace as required. Use cloth soaked in gun cleaner or steel wool to clean and remove buildup of mixed material from rod.
- If valving rod is replaced, reset forward stop.
- 10. Clean mixing module.
 - Ensure cleanout tool size matches module size used.
 - a. Insert cleanout tool into pin vise.
 - b. Use cleanout tool to clean module ports. Make sure not to insert tool too far, it will damage inside bore of module. Use cotton swab soaked in gun cleaner to clean bore of module.





FIG. 20: Clean Module Ports

Parts


GX-8 Gun Final Assembly (297678)



GX-8 Gun Final Assembly (297678)

Ref				Ref No.	Part No	Description	Qtv.
No.	Part No.	Description	Qty.	13		NUT, jam	
1		HOSE, air, 1/4 in. x 23 in. (F x F)	1	14		HANDLE, assembly	1
2		GASKET, block, gasket	2	15		RETAINER, PCD	1
3	295623	VALVE, check, A	1	16	297341	ROD, valving	1
4			1	17	297193	SCREEN, gun block, 100 mesh	2
5		PLUG, coupler		18	297686	SCREW, screen, iso	1
6		Coupler, line, air	1	19	297687	SCREW, screen, res	1
8		PACKING, O-ring	1	20	295437	PACKING, seal, rear	1
9		SCREW, mounting, block, coupling	1	21	297912	MODULE, fan, 013	1
10	297680	NUT, seal, rear	1	22	297192	TIP, fan, 201	1
11	297681	RETAINER, screen	2	23	297705	AIR Cap	1
12	297682	SCREW, mounting, block, gun	1	24	297706	BLOCK, gun	1

GX-8 Handle Assembly (297702)




Parts

GX-8 Handle Assembly (297702)

9 /1	U I I MIIIC						
		• • • •		No.	Part No.	Description	Qty.
Def				89	296538	RING, retaining	1
Ref	Devision	Description	0	90	297689	HANDLE, gun	1
No.		Description	Qty.	91	297690	CYLINDER, air	1
72	295435	SEAL, u-cup	1	92	295686	LINER, valve	1
73	295709	SCREW, cap, socket head	2	93	297722	SPOOL, valve	1
74		PLUG, pipe	1	94	295688	NUT, retainer, valve	1
75	295732	SCREW, cap, sh, 8-32 x 1/4 LG	1	95	295689	SEAT, spring	1
76	103337	PACKING, ring	3	96	295436	SPRING	1
77	106555	PACKING, ring	4	97	297691	PISTON, assembly	1
79	C02032		1	98	296529	CAP, end	1
80	295496	SEAL, u-cup	1	99	297693	NEEDLE, adjust, air	1
81	295692	TRIGGER, gun, spray	1	100		KNOB, gap	1
82	116624	SCREW, set, socket head	2	101		PIN, stop	1
83	295693	PLUG, pipe	1	102		SPRING, piston	1
84	295442	SPRING	1	103		BRACKET, assembly	1
85	108103	PACKING, ring	1	104	114054	PACKING, ring	1
86	168518	PACKING, ring	1	105	C20004	SCREW, cap	2
87	295665	FITTING, nipple, pipe	1	106	295685	RING	4
88	295671	SCREW, mounting, trigger	1				

Ref



GX-8P Spray Gun Final Assembly (297860)

FIG. 21: GX-8P Spray Gun Final Assembly

GX-8P Spray Gun Final Assembly (297860)

Ref.				Ref.			
	Part No	Description	Otv	No.	Part No.	Description	Qty.
No. 107 108 109 110 111 112 113 114 115	Part No. 295184 295801 295623 295624 295596 208536 103656 106560 295433	Description HOSE, air, 1/4 X 23 in. (F X F) GASKET, block, gasket VALVE, check, A VALVE, check, B PLUG, coupler COUPLER, line, air FITTING, pipe, hex PACKING, o-ring SCREW, mounting, block,	Qty. 1 1 1 1 1 1 1 1	No. 121 122 123 124 125 126 127 128 129	Part No. 295341 297861 297193 297686 297687 295437 297705 112307 297706	Description ROD, valving CYLINDER, GX-8P, auto SCREEN, gun block, 100 mesh SCREW, screen, iso SCREW, screen, res PACKING, seal, rear AIR, cap ELBOW, street BLOCK, gun	Qty. 1 2 1 1 1 1 1
116 117 118 119 120	297680 297681 297682 297683 297684	coupling NUT, seal, rear RETAINER, screen SCREW, mounting, block, gun NUT, jam RETAINER, pod	1 2 1 1	130 131	297192 297912	TIP, fan, 201 MODULE, fan, 013	1 1

(CD) 0) Ø Ø ′ **50**[^] Ø -Co **N**.


GX-8P Auto Cylinder Assembly (297861)

FIG. 22: GX-8P Auto Cylinder Assembly

GX-8P Auto Cylinder (297861)


Def	:			Ref	-		
Ref		Description	011/	No.	Part No.	Description	Qty.
	Part No.	Description	Qty.	42	297881	VALVE, control	1
26	295435	SEAL, u-cup	1	43	297882	MANIFOLD, air valve	1
27	295709	SCREW, cap, socket head	4	44	297883	GASKET	1
28	295732	SCREW, cap, sh,	1	45	296538	RING, retaining	1
		8-32 X 1/4 LG		46	297690	CYLINDER, air	1
29	104376	SCREW, cap, sch	2	47	295436	SPRING	1
30	297743	TIE, cable, #6	1	48	297691	PISTON, assembly	1
31	C20888	PACKING, o-ring	2	49	296529	CAP, end	1
32	103337	PACKING, o-ring	4	50	297884	NEEDLE, air adjust	1
33	297253	WASHER, helical, .188 in.	4	51	296530	KNOB, gap	. 1
		diameter		52	296526	PIN, stop	1
34	104705	SCREW, cap, sch	2	53	297885	BRACKET	1
35	295496	SEAL, u-cup	1	54	297886	BLOCK, valve mount	1
36	116624	SCREW, set, socket head	2	56	297888	PLATE, mounting, gun	1
37	297862	SCREW, cap, flat head	1	57	297889	PLATE, cover, manifold	1
38	108103	PACKING, o-ring	1	58	295416	SPRING, piston	1
39	168518	PACKING, o-ring	1	59	114054	PACKING, o-ring	1
40	297863	SCREW, cap, socket head	3	60	C20004	SCREW, cap	1
41	297975	WASHER, lock	3	61	295685	O-RING	- 1
		_ ,	-	01	230000		4

Auto GX-8P Optional Parts



Ref No.	Part No.	Description	Qty.
1	297899	KIT, auto, GX-8 Gun	1
2	298752	WIRE, 10 ft, extension harness	1
3	298753	WIRE, 25 ft, extension harness	1
4	298754	WIRE, 50 ft, extension harness	1
5	298611	ENCODER, assembly	1
6	299083	CABLE, VMU, extension 25 ft	1
7	297730	CABLE, encoder, assembly	1
8	297741	CONTROL BOX, TX50 processor	· 1


Coupling Block Assembly (295383)



Ref.

No.	Part No.	Description	Qty.
62	295662	Pipe plug, flush seal, 1/8 in.	2
63	295888	B-swivel fitting	1
64	295889	A-swivel fitting	1
65	295693	Pipe plug, flush seal, 1/16 in.	2
66	296970	Manual valve assembly	2
67	296215	Coupling block	1

Coupling Block (297902)



Ref.

Qty.
2
2
1

Set-up Chart for GX-8P Modules

Pres- sure (psi)	Output (Ibs/min)	Pattern ≭Dia. (inches)	Module Part No.	Resin Port Size	No. Orifices	Iso Port Size	No. Orifices	Тір
Round Spray Pattern								
2500	1.0	4.0	295377	.013	1	.013	1	295339 (020)
2500	1.4	5.0	295377	.013	1	.013	1	295428 (024)
Fan Spray Pattern								
2500	1.0	6	295338	.013	1	.013	1	297192 (201)
2500	1.4	7	295338	.013	1	.013	1	297841 (202)

¥ At 18-24 in. above substrate

GX-8P Model Specifications

Module/Tip Data for Chemical Sprayed at 2500 PSI									
≭ Module Kit	Cleanout Drill	Тір	*Pattern	∜Output (Ibs/min)					
Fan Spray Pattern									
295338	297914 (.013 diameter)	297192 (201)	6 in. wide	1.0					
(.098 diameter)		297841 (202)	7 in. wide	1.4					
Round Spray Pattern									
295377	297914 (.018 diameter)	295339 (020)	4 in. diameter	1.0					
(.098 diameter)		295428 (024)	5 in. diameter	1.4					

* Actual results may vary due to chemical system characteristics, temperature, pressure, and ratio.

Includes appropriate cleanout drills.

Tool Kits

297966 GX-8P Tool Kit

Technical Data

Category	Data
Air Supply	100-125 psi (7-9 bars)
Maximum Operating Pressure	3500 psi (24 MPa, 240 bar)
Maximum Output *	0.4 gallons/min. (1.52 liters/min.)
Minimum Output *	0.1 gallons/min. (0.38 liters/min.)
Height	7 in. (17.8 cm)
Length	7.5 in. (19 cm)
Width	2.5 in. (6.25 cm)
Weight	2.3 lbs. (1.04 kg)
Mixing	Internal impingement, airless atomization, sol- vent-free, mechanically self cleaning
Wetted Parts	Stainless Steel, Carbon Steel, HDPE, Acetal

* Theoretical: actual results will vary with operating conditions.

Notes

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor. **Phone:** 612-623-6921 or **Toll Free:** 1-800-328-0211, **Fax:** 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice. MM 311321

> Graco Headquarters: Minneapolis International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com Printed in USA 311338A Rev. 9/2006