

E-Flo™ Plus Electric Circulation Pump

311592 rev. B


Durable, energy efficient piston pumps for high volume paint circulation applications.

See page 3 for model information, including maximum working pressure and approvals.



Important Safety Instructions

Read all warnings and instructions in this manual.
Save these instructions.



ti8317a

PROVEN QUALITY. LEADING TECHNOLOGY.


Contents

Models	3	Connect Fluid Lines	11
E-Flo Plus Electric Circulation Pumps	3	Electric Motor	12
Maximum Working Pressure and Pump Operational Limits	3	Electric Motor Specifications	12
Approvals	3	Motor Wiring	12
Related Manuals	3	Install the Motor	12
Warnings	4	Electrical Noise Filter	14
System Components	6	Variable Frequency Drive Accessory (VFD)	15
Hazardous Area	6	VFD Installation	15
Non-Hazardous Area	6	VFD Wiring	15
System Wiring Schematics	8	Ethernet Interface (optional)	15
Power Supply Requirements	10	120373 Local Control Box (optional accessory) .	16
Power Disconnect Switch	10	Pneumatic Back Pressure Regulator (optional) .	17
Hazardous Area Cabling and Conduit Requirements (Explosion Proof)	10	Dimensions	18
Increased Safety (European)	10	Technical Data	19
288036 Power Module	10	Graco Standard Warranty	20
Pump Location	11	Graco Information	20
Environmental Conditions	11		
Clearance	11		
15H884 Floor Stand	11		

Models

E-Flo Plus Electric Circulation Pumps

Check your pump's identification plate (ID) for the 6-digit part number of your pump. Use the following matrix to define the construction of your pump, based on the six digits. For example, Pump Part No. **E P 2 1 6 0** represents electric power (**E**), pump (**P**), 230/460V motor (**2**), sensor circuit installed (**1**), and 2000 cc Maxlife lower (**6**). The last digit (**0**) is unassigned. To order replacement parts, see the Repair-Parts manual 311594.



E	P	2		1		6		0	
First Digit	Second Digit	Third Digit		Fourth Digit		Fifth Digit		Sixth Digit	
Power Source	Equipment Style	Motor		Sensor Circuit		Lower Size		Unassigned	
E (electric)	P (pump)	0	No motor	0	No circuit	1	1000 cc	0	None assigned
		1	230/400V ATEX	1	Circuit installed	2	1500 cc		
		2	230/460V UL/CSA			3	2000 cc		
						4	1000 cc Maxlife		
						5	1500 cc Maxlife		
						6	2000 cc Maxlife		

Maximum Working Pressure and Pump Operational Limits

1000 cc Pumps: 460 psi (3.22 MPa, 32.2 bar) Maximum Working Pressure

1500 cc Pumps: 330 psi (2.31 MPa, 23.1 bar) Maximum Working Pressure

2000 cc Pumps: 250 psi (1.75 MPa, 17.5 bar) Maximum Working Pressure

See **Technical Data**, page 21, for pump operational limits.

Approvals

The E-Flo Plus Pump meets requirements of the following approval agencies.







Related Manuals







Manual	Description
311593	E-Flo Plus Operation Manual
311594	E-Flo Plus Repair-Parts Manual
311595	Pneumatic Back Pressure Regulator
311596	Variable Frequency Drive Instructions
311603	Sensor Circuit Option

Refer to the individual components for other specific hazardous location listings.

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbol refers to procedure-specific risk. Refer back to these warnings. Additional, product-specific warnings may be found throughout the body of this manual where applicable.


 WARNING	
	<p>FIRE AND EXPLOSION HAZARD</p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> • Use equipment only in well ventilated area. • Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). • Keep work area free of debris, including solvent, rags and gasoline. • Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present. • Ground all equipment in the work area. See Grounding instructions. • Use only grounded hoses. • Hold gun firmly to side of grounded pail when triggering into pail. • If there is static sparking or you feel a shock, stop operation immediately. Do not use equipment until you identify and correct the problem. • Keep a working fire extinguisher in the work area.
	<p>EQUIPMENT MISUSE HAZARD</p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> • Do not operate the unit when fatigued or under the influence of drugs or alcohol. • Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Data in all equipment manuals. • Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS forms from distributor or retailer. • Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. • Do not alter or modify equipment. • Use equipment only for its intended purpose. Call your distributor for information. • Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. • Do not kink or over bend hoses or use hoses to pull equipment. • Keep children and animals away from work area. • Comply with all applicable safety regulations.
	<p>ELECTRIC SHOCK HAZARD</p> <p>Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment. • Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.

 WARNING	
	<p>PRESSURIZED EQUIPMENT HAZARD</p> <p>Fluid from the gun/dispense valve, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.</p> <ul style="list-style-type: none"> • Follow Pressure Relief Procedure in this manual, when you stop spraying and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.
	<p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure in this manual. Disconnect power or air supply.
	<p>TOXIC FLUID OR FUMES HAZARD</p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> • Read MSDS's to know the specific hazards of the fluids you are using. • Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines. • Always wear impervious gloves when spraying or cleaning equipment.
	<p>PERSONAL PROTECTIVE EQUIPMENT</p> <p>You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, inhalation of toxic fumes, burns, and hearing loss. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> • Protective eyewear • Clothing and respirator as recommended by the fluid and solvent manufacturer • Gloves • Hearing protection
	<p>BURN HAZARD</p> <p>Equipment surfaces and fluid that's heated can become very hot during operation. To avoid severe burns, do not touch hot fluid or equipment. Wait until equipment/fluid has cooled completely.</p>

System Components

FIG. 1 illustrates a typical North American system installation, showing the major system components. Also see the wiring schematic in FIG. 2 and FIG. 3.

Hazardous Area



See FIG. 1. The following system components are approved for use in a hazardous area:

- E-Flo Plus Electric Circulation Pump
- Sensor Control Circuit (option). See intrinsic safety installation requirements below.

Circuit Assembly Intrinsic Safe Control		
PART NO.	SERIES	SERIAL

Conforms to FM std 3600 & 3610
CAN/CSA 22.2 No. 157-92 & No. 1010.1-92 for use in Class I Div 1 Group C & D T3 Hazardous locations

EEEx ib IIB T3
FM 06 ATEX 0025X

Intrinsically Safe (IS) System. Install per IS Control Drawing No. 288110. Class I, Division 1, Group C & D T3 Hazardous Locations

Read Instruction Manual - Warning: Substitution of components may impair intrinsic safety.

MIN / MAX TEMP RANGE: 0° - 50°C (32° - 122°F)

Intrinsic Safe Input Parameters		
	TDC Circuit	Pressure Circuit
Ui	15 V	31.5 V
Ii	60 mA	33 mA
Pi	200 mW	.95 W
Ci	220 nF	.036 uF
Li	280 uH	.44 uH

GRACO INC.
P.O. Box 1441
Minneapolis, MN
55440 U.S.A.

Artwork No. 293140

Sensor Circuit Wetted Parts

Pressure transducer: 17-4 PH stainless steel


- Explosion-Proof Electric Motor
- Local Control Box (accessory)
- Pneumatic Back Pressure Regulator (accessory)

All other components shown in FIG. 1 **must** be installed in a **non-hazardous area**.

Non-Hazardous Area

See FIG. 1. Install the following components in a non-hazardous area:

- System Power Disconnect Switch
- Electrical Noise Filter (accessory)
- Variable Frequency Drive (accessory)
- Power Module (accessory)
- 3-Way Pneumatic Solenoid Valve (accessory)



ti8651a

FIG. 1: Typical Installation**Key:**

- | | | | |
|-----|--|------|---|
| A | E-Flo Plus Electric Circulation Pump | P* | Pump Stand |
| B* | Explosion-Proof Electric Motor | R** | Fluid Inlet Line |
| C* | Local Control Box | S** | Fluid Outlet Line |
| D* | Variable Frequency Drive (VFD) | T** | Fluid Return Line |
| E** | System Power Disconnect Switch | U* | Pneumatic Back Pressure Regulator |
| F* | Electrical Noise Filter | V** | Air Supply Lines to 3-Way Solenoid Valve |
| G* | Power Module | W** | Air Line, Solenoid Valve to Back Pressure Regulator |
| H* | VFD/BPR Pneumatic Control Kit | X** | Ethernet Cable, VFD to Computer |
| J** | Electric Power Cable, VFD to Electric Motor | Y** | Personal Computer |
| K** | Electric Control Cable, Local Control Box to VFD | Z** | Pump Ground Wire |
| L** | Explosion-Proof Seal Fittings | AA* | Explosion-Proof Electric Agitator |
| M** | Electric IS Control Cable, Power Module to Pump Sensor Circuit | AB** | Pressure Relief |
| N** | Electric Cable, VFD to 3-Way Solenoid Valve (2 meters provided by Graco) | AC* | Fluid Filters |
| | | AD* | Fluid Line Isolation Valves |
- * Option available from Graco.
** Supplied by integrator.

System Wiring Schematics

FIG. 2 shows components that must be installed in a non-hazardous location.

FIG. 3 shows components approved for installation in a hazardous location.




FIG. 2: System Wiring Schematic, Non-Hazardous Location Only

GROUP II, CATEGORY 2 - ZONE 1, GAS, (ATEX ONLY)
CLASS I, DIV. 1, GROUP C&D T3 (CANADA)

WHITE
GREEN
RED
BLACK

J2
3
4
J3
1
2
3

IS SENSOR
CIRCUIT
BOARD

J2
1 2
+ (BRN)
- (BLU)

TDC
NAMUR
SENSOR

J1
1 2
3 4
5 (RED)
(GRN)
(WHT)
(BLK)

PRESSURE
TRANSDUCER

LOCAL CONTROL

COM
TRIP RESET
RUN/STOP
LOCAL/REMOTE
JOG
SECURE DISABLE
24V (+)

BLU - 18 GA MTW WIRE
BLU - 18 GA MTW WIRE
GRN/YLW - 14 GA ALPHA WIRE P/N: V16014/EQUIV.
BLK - 14 GA ALPHA WIRE P/N: V16014/EQUIV.
BLK - 14 GA ALPHA WIRE P/N: V16014/EQUIV.
BLK - 14 GA ALPHA WIRE P/N: V16014/EQUIV.

**SEE DETAIL
BELOW**

SEE ABOVE

UL EXPLOSION PROOF MOTOR
230/460 VAC (UL)

MOTOR JUNCTION BOX

LOW VOLTAGE - 200/230 () OR HIGH VOLTAGE - 400/460 ()

OVER-TEMP
SWITCH

P-1 P-2
GRND

T-4 T-5 T-6
T-7 T-8 T-9
T-1 T-2 T-3
GRND



ATEX EXPLOSION PROOF MOTOR
230/400VAC

MOTOR JUNCTION BOX

W2 U2 V2
U1 V1 W1
PTC

9

Power Supply Requirements



Improper wiring may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician perform any electrical work. Be sure your installation complies with all National, State and Local safety and fire codes.

See TABLE 1 for power supply requirements. The system requires a dedicated circuit protected with a 20 A circuit breaker.

Table 1: Power Supply Specifications

Voltage	Phase	Hz	Minimum Circuit Breaker Size
230/400V	3	50/60	20 A/15 A
230/460V	3	50/60	20 A/15 A

Power Disconnect Switch

See FIG. 1 on page 7. Install a power disconnect switch (E) in the non-hazardous area. This switch must shut off and lock-out all electric power to the system.

Hazardous Area Cabling and Conduit Requirements (Explosion Proof)



All electrical wiring in the hazardous area must be encased in Class I, Division I, Group C and D approved explosion-proof conduit.

Wire passages from the hazardous to the non-hazardous area must be secured by explosion-proof seal fittings (L).

Increased Safety (European)

Use appropriate cables, connectors, and cable glands rated for ATEX II 2 G. Follow all National and Local electric codes.

Table 2: Cabling Specifications

Connection Points	Wire Size, AWG (mm ²)	Maximum Length ft (m)
VFD to Motor	14 (2.5)	330 (100)
Motor Overtemperature Switch to VFD	18 (0.75)	330 (100)
Local Control Box to VFD	16 (1.5)	330 (100)

288036 Power Module

The 288036 Power Module transforms the high voltage power supply to a 24 Vdc input for the pump sensor circuit. See manual 311608 for further information.

See FIG. 1 on page 7. Install the power module (G) in the non-hazardous area.

See FIG. 2 Electrical Schematic for module wiring connections.

Pump Location

Environmental Conditions

See **Technical Data**, page 19, for recommended ambient temperature range and environmental conditions.

Clearance

When selecting the location for the pump, keep the following in mind:

- There must be sufficient space on all sides of the pump for installation, operator access, repair, and air circulation. See **Dimensions**, page 18. See manual 311593 for maintenance requirements.
- Ensure that the mounting surface and mounting hardware are strong enough to support the weight of the equipment, fluid, hoses, and stress caused during operation.
- There must be a pump disable switch within easy reach of the pump. The Secure Disable switch on the 120373 Local Control Box Accessory provides this function. See page 16.

15H884 Floor Stand

Floor Stand 15H884 is available as an accessory. See 406638 for assembly and mounting instructions.

Connect Fluid Lines

See FIG. 4. The fluid manifolds are secured to the pumps with 1-1/2 in. clamps and sanitary gaskets (CG). Manifolds can be oriented in either direction. Connect the fluid line (R) to the manifold (MF) using 2 in. clamps and sanitary gaskets (SC). Optional fittings are available. See TABLE 3.

Table 3: Fluid Fittings, Clamps, and Sanitary Gaskets

Part No.	Description
15J423	Converts 2 in. sanitary to 2 in. npt adapter
15J422	Converts 1-1/2 in. sanitary to 1-1/2 in. npt adapter
15J639	Converts 2 in. sanitary to 1-1/2 in. sanitary reducer adapter
120350	1-1/2 in. Sanitary Clamp
120620	2 in. Sanitary Clamp
120631	2 in. Sanitary Gasket, PTFE
680454	1-1/2 in. Sanitary Gasket, Virgin PTFE
120351	1-1/2 in. Sanitary Gasket, PTFE encapsulated fluoroelastomer

 Use 120351 Gaskets at these locations.






FIG. 4. Fluid Connection (Pump Inlet Shown)


Electric Motor

						
<p>Improper wiring may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician perform any electrical work. Be sure your installation complies with all National, State and Local safety and fire codes.</p>						

Electric Motor Specifications

The electric motor must be approved as explosion-proof for use in a hazardous area. See **Approvals**, page 3, for applicable agencies and requirements. All wiring must meet Local and National electric codes for hazardous area.

See TABLE 4 for motor specifications. If motor is not purchased with pump: NEMA 184TC Frame is required to mate with gear reducer. Adapter is available (15J893 is an option) for IEC 112M/B5 Frame.

 Graco does not support the use of the Graco VFD CAM mode on motors not supplied by Graco.

Motor Wiring

See the **System Wiring Schematics** on pages 8 and 9.

Install an explosion-proof seal fitting in the wall separating the hazardous area from the non-hazardous area.


Use explosion-proof conduit or increased safety protection concepts to run wires between the motor junction box and the variable frequency drive (VFD).

Use 14 gauge wire (3 wires plus ground) to connect the VFD and the motor.

Use 18 gauge wire between pins 8 and 11 on the VFD and the motor overtemperature switch.

Motor must be wired to rotate fan counter-clockwise when viewed from fan end of motor. See FIG. 6 or FIG. 7.

Install the Motor

 If the pump is purchased without a motor, you must order a coupler kit to mate with the gear reducer.

- To install a NEMA 184 TC Frame electric motor, order Motor Coupler Kit 15H880. See manual 311605.
- To install a IEC 112M/B5 Frame electric motor, order Motor Adapter Kit 15J893. See manual 311605.

- See FIG. 5. Assemble the key (20) and two set-screws (31) in the coupler (28). Slide the coupler into the gear reducer so the key mates with the input shaft (105). Slide on until coupler and key bottom on the stop on shaft. Tighten setscrews to 66-78 in-lb (7.4-8.8 N•m). Apply antiseize lubricant to bore of coupling.

Table 4: Electric Motor Specifications

Motor Kit Part No.	Voltage	Phase	Supply Frequency	Horsepower	rpm	Full Load Torque
255226	230/400V	3	50 Hz	5	1500 (4 pole)	15 ft-lb (20.3 N•m)
255225	230/460V	3	60 Hz	5	1800 (4 pole)	15 ft-lb (20.3 N•m)

 Apply antiseize lubricant to bore of coupler (28).






FIG. 5. Install the Coupler


 When installing an IEC 112M/B5 Frame electric motor, ensure that the motor adapter (60) and screws (59) are in place before mounting the motor on the gear reducer. Torque screws to 75-80 ft-lb (102-108 N•m). See FIG. 7.

2. See FIG. 6 or FIG. 7. Lift the motor (19) into position. Align the key on the motor shaft with the mating slot of the motor coupler, and the four mounting holes with the holes in the gear reducer (1). Slide the motor into place.
3. While one person supports the motor (19), install the screws (37). Torque to 75-80 ft-lb (102-108 N•m).



Motor Rotation
(counter-clockwise as viewed from fan end)

FIG. 6. NEMA 184 TC Frame Electric Motors



Motor Rotation
(counter-clockwise as viewed from fan end)

FIG. 7. IEC 112M/B5 Frame Electric Motors

Electrical Noise Filter

See FIG. 1 on page 7 and FIG. 2 Electrical Schematic on page 8. Install the electrical noise filter in the non-hazardous area, upstream of the VFD.

Graco supplies accessory noise filters, depending on your system voltage. See TABLE 5.

Table 5: Electrical Noise Filters

Part No.	Rated Voltage	Amps	Mounting Hole Diagram
120365	230 Vac	32	FIG. 8
120366	480 Vac	16	FIG. 9




FIG. 8. 120365 Filter Mounting Holes




FIG. 9. 120366 Filter Mounting Holes

Variable Frequency Drive Accessory (VFD)

Use a variable frequency drive (VFD) accessory to provide motor drive control to the pump. Graco supplies accessory VFDs that optimize pump performance. Order Part No. 15J753 (200-240 Vac) or 15J754 (380-480 Vac), depending on your system voltage.

See VFD manual 311596 for further information.

VFD Installation

See FIG. 1 on page 7. Install the VFD (D) in the non-hazardous area.

Install an electrical noise filter (F) upstream of the VFD. See page 14.

VFD Wiring

See FIG. 2 Electrical Schematic on page 8f or VFD wiring connections.

- Connect 14 gauge or larger wires to terminals U, V, W, and GND on the VFD. See **Motor Wiring**, page 12.
- Connect 18 gauge wires between pins 8 and 11 on the VFD and the motor overtemperature switch.

Ethernet Interface (optional)

To operate the system from a personal computer, order Ethernet Interface Kit 15H885 for the VFD. See FIG. 10. The kit includes manual 311612.

See FIG. 1 on page 7. Use Category V Ethernet cable (X) to connect the computer (Y) to the VFD (D).




FIG. 10. Ethernet Interface Module

120373 Local Control Box (optional accessory)

See FIG. 1 on page 7, and FIG. 11. Install the local control box (C) in the hazardous area as close to pump as possible.

See FIG. 2 on page 8 to wire the local control box to the VFD. All cabling in the hazardous area must be in explosion-proof conduit and secured by explosion-proof seal fittings. See **Hazardous Area Cabling and Conduit Requirements (Explosion Proof)**, page 10 and TABLE 2.

Local Control Box has 1 in. npt conduit connection point on top and bottom for installation convenience.





FIG. 11. 120373 Local Control

Pneumatic Back Pressure Regulator (optional)

See FIG. 1 on page 7, and FIG. 12. Install the back pressure regulator (U) in the fluid return line in the hazardous area. Three sizes of fluid inlets and outlets (FI, FO) are available. See TABLE 6.

Table 6: Back Pressure Regulator Fluid Inlet and Outlet Sizes

BPR	Fluid Inlet and Outlet Size
288117	1-1/4 npt(f)
288262	2 in. sanitary
288311	1-1/2 npt(f)

To control air pressure to the BPR, install Kit 15K012 (H) in the non-hazardous area. The kit includes two air regulators and a 3-way solenoid valve. Connect an electrically conductive air hose to the 5/32 in. tube fitting (AF) on the BPR.

See FIG. 2 on page 8 to wire the 3-way solenoid valve to pin 26 and common pin of the VFD.








FIG. 12. Back Pressure Regulator

Dimensions

E-Flo Plus Electric Circulation Pump




Mounting Hole Details (see key below)



Key:


Ref.	Description	in. (mm)
A	Width between lower mounting holes	3.5 (88.9)
B	Width between upper mounting holes	5.125 (130.2)
C	Height from center of fluid outlet to lower mounting holes	9.50 (241.3)
D	Height from center of fluid outlet to upper mounting holes	12.718 (323.0)
E	Depth from upper mounting hole surface to center of fluid outlet	4.07 (103.4)
F	Depth from outermost lower mounting hole to face of fluid inlet/outlet ports	12.549 (318.7)
G	Width from centerline of lower mounting holes to centerline of fluid outlet	0.23 (5.8 mm)

Pump Stand (Accessory)



Technical Data

Maximum Working Pressure	1000 cc Pumps: 460 psi (3.22 MPa, 32.2 bar) 1500 cc Pumps: 330 psi (2.31 MPa, 23.1 bar) 2000 cc Pumps: 250 psi (1.75 MPa, 17.5 bar)
Electrical Requirements	European Models: 230/400 Vac, 3 phase, 20 A North American Models: 230/460 Vac, 3 phase, 15 A
Ambient Temperature Range	32-104°F (0-40°C)
Maximum Fluid Output (at 20 cpm)	22.6 gpm (85.6 liters per min) with 2000 cc lowers. See chart below.
Fluid Inlet and Outlet Size	2 in. Tri-clamp
Gear Reducer Oil Capacity	2 quarts (1.9 liters)
Required Gear Reducer Lubricant	ISO VG220 grade oil (Graco Part No. 288414)
Weight (with motor and 2000 cc lowers)	Pump: 550 lb (249 kg)
Wetted Parts.	Lower: see manual 311690 300 Series SST, CV-75, 17-4 PH SST, PTFE
Maximum Production Motor Speed	1500 rpm (50 Hz)
Maximum Motor Torque	15 ft-lb (20.3 N•m)
Gear Reduction Ratio	75.16:1



Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

MM 311592

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

1/2007 Revised 3/2007