

# T2 2:1 Ratio Transfer Pump

311882 rev.A

***For use with polyurethane foam, polyurea, and similar non-flammable materials.  
Not for use in explosive atmospheres.***

## **Model 295616**

*180 psi (1.2 MPa, 12 bar) Maximum Air Working Pressure*

*405 psi (2.7 MPa, 27 bar) Maximum Fluid Working Pressure*



### **Important Safety Instructions**

Read all warnings and instructions in this manual.  
Save these instructions.



ti9889a

**PROVEN QUALITY. LEADING TECHNOLOGY.**






# Contents

|                                                  |    |                                      |    |
|--------------------------------------------------|----|--------------------------------------|----|
| <b>Warnings</b> .....                            | 2  | <b>Air Motor Repair</b> .....        | 11 |
| <b>Typical Installation</b> .....                | 4  | <b>Pump Lower Repair</b> .....       | 12 |
| <b>Moisture Sensitivity of Isocyanates</b> ..... | 7  | <b>Reassembly</b> .....              | 14 |
| Isocyanate Hazard .....                          | 7  | <b>Troubleshooting</b> .....         | 15 |
| Foam Self-Ignition .....                         | 7  | <b>Parts</b> .....                   | 16 |
| Keep Components A and B Separate .....           | 7  | <b>Technical Data</b> .....          | 18 |
| Changing Materials .....                         | 7  | Dimensions .....                     | 18 |
| <b>Setup</b> .....                               | 8  | Performance Chart .....              | 19 |
| Grounding the System .....                       | 9  | <b>Graco Standard Warranty</b> ..... | 20 |
| <b>Operation</b> .....                           | 10 | <b>Graco Information</b> .....       | 20 |
| Pressure Relief Procedure .....                  | 10 |                                      |    |
| Flushing .....                                   | 10 |                                      |    |
| Daily Startup .....                              | 10 |                                      |    |
| Daily Shutdown .....                             | 10 |                                      |    |

## Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbol refers to procedure-specific risk. Refer back to these warnings. Additional, product-specific warnings may be found throughout the body of this manual where applicable.

|  <b>WARNING</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read MSDS's to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> <li>• Always wear impervious gloves when spraying or cleaning equipment.</li> </ul>                                                                   |
|                 | <p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, inhalation of toxic fumes, burns, and hearing loss. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear</li> <li>• Clothing and respirator as recommended by the fluid and solvent manufacturer</li> <li>• Gloves</li> <li>• Hearing protection</li> </ul> |

 **WARNING**
**EQUIPMENT MISUSE HAZARD**

Misuse can cause death or serious injury.

- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Data** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Data** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS forms from distributor or retailer.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.

**PRESSURIZED EQUIPMENT HAZARD**

Fluid from the gun/dispense valve, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.

- Follow **Pressure Relief Procedure** in this manual, when you stop spraying and before cleaning, checking, or servicing equipment.
- Tighten all fluid connections before operating the equipment.
- Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.

**MOVING PARTS HAZARD**

Moving parts can pinch or amputate fingers and other body parts.


- Keep clear of moving parts.
- Do not operate equipment with protective guards or covers removed.
- Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the **Pressure Relief Procedure** in this manual. Disconnect power or air supply.

# Typical Installation

## Typical Installation, without Circulation

### Key for FIG. 1

- |   |                                                      |   |                                  |
|---|------------------------------------------------------|---|----------------------------------|
| A | Reactor Proportioner                                 | H | Waste Containers                 |
| B | Heated Hose                                          | J | Fluid Supply Lines (217382)      |
| C | Fluid Temperature Sensor (FTS)                       | K | Feed Pumps                       |
| D | Heated Whip Hose                                     | L | Agitator                         |
| E | Fusion Spray Gun                                     | M | Desiccant Dryer                  |
| F | Proportioner and Gun Air Supply Hose                 | N | Bleed Lines/Over Pressure Relief |
| G | Feed Pump Air Supply Lines (3/8 in. (76 mm) ID min.) | P | Gun Fluid Manifold               |




\* Shown exposed for clarity. Wrap with tape during operation.

FIG. 1: Typical Installation, without Circulation

## Typical Installation, with Circulation

### Key for FIG. 2

- |   |                                      |   |                                                     |
|---|--------------------------------------|---|-----------------------------------------------------|
| A | Reactor Proportioner                 | G | Feed Pump Air Supply Lines (3/8 in. (76 mm) ID min) |
| B | Heated Hose                          | J | Fluid Supply Lines                                  |
| C | Fluid Temperature Sensor (FTS)       | K | Feed Pumps                                          |
| D | Heated Whip Hose                     | L | Agitator                                            |
| E | Fusion Spray Gun                     | M | Desiccant Dryer                                     |
| F | Proportioner and Gun Air Supply Hose | N | Recirculation/Over Pressure Relief Return Hoses     |
|   |                                      | P | Gun Fluid Manifold                                  |



\* Shown exposed for clarity. Wrap with tape during operation.

FIG. 2: Typical Installation, with Circulation

# Typical Installation for Lubrication Applications

## Key for FIG. 3

- |   |                                                  |   |                              |
|---|--------------------------------------------------|---|------------------------------|
| A | Pump Air Regulator                               | G | Grounded Air Hose            |
| B | Air Line Lubricator                              | H | Grounded Fluid Hose          |
| C | Air Line Filter                                  | J | Pump Fluid Inlet             |
| D | Bleed-Type Master Air Valve (required, for pump) | K | 1/4 npt(f) Pump Air Inlet    |
| E | Fluid Drain Valve (required)                     | L | 1/2 npt(f) Pump Fluid Outlet |
| F | Bung Adapter                                     |   |                              |





FIG. 3: Typical Installation for Lubrication Applications

# Moisture Sensitivity of Isocyanates





Isocyanates (ISO) are catalysts used in two component foam and polyurea coatings. ISO will react with moisture (such as humidity) to form small, hard, abrasive crystals, which become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity. If used, this partially cured ISO will reduce performance and the life of all wetted parts.

 The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.



To prevent exposing ISO to moisture:

- Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. **Never** store ISO in an open container.
- Use moisture-proof hoses specifically designed for ISO, such as those supplied with your system.
- Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use.
- Never use solvent on one side if it has been contaminated from the other side.
- Always lubricate threaded parts with Part 217374 ISO pump oil or grease when reassembling.

## Isocyanate Hazard

|                                                                                                                                                                                                                               |                                                                                    |                                                                                     |                                                                                     |  |  |  |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--|--|--|
|                                                                                                                                              |  |  |  |  |  |  |
| <p>Read material manufacturer's warnings and material MSDS to know the specific hazards of isocyanates. Use equipment in a well-ventilated area. Wear respirator, gloves, and protective clothing when using isocyanates.</p> |                                                                                    |                                                                                     |                                                                                     |  |  |  |

## Foam Self-Ignition

|                                                                                                                               |                                                                                    |  |  |  |  |  |
|-------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|--|--|--|--|--|
|                                              |  |  |  |  |  |  |
| <p>Some materials may become self-igniting if applied too thick. Read material manufacturer's warnings and material MSDS.</p> |                                                                                    |  |  |  |  |  |

## Keep Components A and B Separate

| CAUTION                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>To prevent cross-contamination of the equipment's wetted parts, <b>never</b> interchange component A (isocyanate) and component B (resin) parts.</p> |

## Changing Materials

- When changing materials, flush the equipment multiple times to ensure it is thoroughly clean.
- Check with your material manufacturer for chemical compatibility.
- Most materials use ISO on the A side, but some use ISO on the B side.
- Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the B (resin) side.

# Setup

1. Apply thread sealant to the male threads of the air needle valve (48) and the quick disconnect fitting (49) and install. See FIG. 4

⚠ Apply thread sealant




FIG. 4

2. Apply thread sealant to the male outlet fitting (not supplied) and insert into the outlet port. See FIG. 5.

⚠ Apply thread sealant




FIG. 5

3. When applying component labels (70) to pump cap (1) make sure you do not cover the hole in the cap. Use the "A" label for the ISO pump and the "B" label for the resin pump. See FIG. 5 and FIG. 6.




FIG. 6

4. Lubricate the bung adapter inside diameter and mounting threads. Ensure the gasket is in place and screw the bung adapter (51) securely into the bung-hole of the drum. Insert the pump through the adapter and lock it in place. See FIG. 7.

⚠ Lubricate threads




FIG. 7



5. Install air line (3/8 in. (76 mm) ID minimum) with quick disconnect air coupler (52) provided. See FIG. 8.





FIG. 8

2. *Air compressor:* according to manufacturer's recommendations.
3. *Fluid hoses:* use only grounded hoses with a maximum of 500 ft (150 m) combined hose length to ensure grounding continuity. Refer to Hose Grounding Continuity.
4. *Dispensing valve:* grounding is obtained through connection to a properly grounded fluid hose and pump.
5. *Object being sprayed:* according to local code.
6. *Fluid supply container:* according to local code.
7. *All solvent pails used when flushing,* according to local code. Use only metal pails, which are conductive. Do not place the pail on a non-conductive surface, such as paper or cardboard, which interrupts the grounding continuity.
8. *To maintain grounding continuity when flushing or relieving pressure,* always hold a metal part of the spray gun/dispensing valve firmly to the side of a grounded *metal* pail, then trigger the gun/valve.

## Grounding the System



To reduce the risk of static sparking, ground the pump and all other equipment used or located in the pumping area. Check your local electrical code for detailed grounding instructions for your area and type of equipment. **Ground all of this equipment.**

1. *Pump:* Connect Ground Wire (Y) to grounding screw (72) and tighten the screw securely. See FIG. 9. Connect the other end of the wire to a true earth ground. Make certain to comply with all National, State, and Local Electrical Codes.






FIG. 9




# Operation

## Pressure Relief Procedure

|                                                                                                                            |                                                                                   |  |  |  |  |  |
|----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|--|--|--|--|--|
|                                           |  |  |  |  |  |  |
| Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts. |                                                                                   |  |  |  |  |  |

1. Engage trigger lock.
2. Close the bleed-type master air valve.
3. Disengage the trigger lock.
4. Hold a metal part of the dispense valve firmly to a grounded metal pail. Trigger the valve to relieve pressure.
5. Engage the trigger lock.
6. Open all fluid drain valves in the system, having a waste container ready to catch drainage. Leave drain valve(s) open until you are ready to dispense again.
7. If you suspect the nozzle or hose is clogged or that pressure has not been fully relieved after following the steps above, **VERY SLOWLY** loosen the hose end coupling to relieve pressure gradually, then loosen completely. Clear hose or nozzle obstruction.

## Flushing

|                                                                                                                            |                                                                                     |                                                                                     |  |  |  |  |
|----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--|--|--|--|
|                                         |  |  |  |  |  |  |
| Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts. |                                                                                     |                                                                                     |  |  |  |  |

- Flush at the lowest pressure possible. Check connectors for leaks and tighten as necessary.
- Flush with a fluid that is compatible with the fluid being dispensed and the equipment wetted parts.

1. Follow **Pressure Relief Procedure**, page 10.
2. Place suction tube in grounded metal pail containing cleaning fluid.
3. Set pump to lowest possible fluid pressure, and start pump.
4. Hold a metal part of the dispense valve firmly to a grounded metal pail. Trigger the dispense valve until clean solvent dispenses.
5. Remove valve from hose.
6. Follow **Pressure Relief Procedure**, and remove fluid filter and soak in solvent. Replace filter cap.

## Daily Startup

1. Verify that the air needle valve is closed.
2. Connect the air line quick disconnect coupler to the transfer pump
3. Turn on the main air supply.
4. Slowly open the air needle valve until the transfer pump runs slowly.
5. Use the air needle valve to control the pump speed.


| <b>Caution</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Never allow the pump to run dry of the fluid being pumped. A dry pump will quickly accelerate to a high speed and could cause personal injury and/or damage to the pump. If the pump accelerates quickly or starts running too fast, stop it immediately and check the fluid supply. If the supply container is empty or air has been pumped into the lines, refill the container and prime the pump and the lines with fluid, or flush and leave it filled with a compatible solvent. Be sure to eliminate all air from the fluid system. |
| Do not attempt to operate pump unless it is securely mounted in a drum.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

## Daily Shutdown

1. Disconnect air line coupler.
2. When air pressure is bled off, close the air line needle valve.


# Air Motor Repair

1. Remove cap (1), cylinder (4), and square gaskets (3\*). Inspect all parts, including spring under cap (not shown in FIG. 10) for damage and replace if necessary. See FIG. 10.




**FIG. 10**

3. Remove 3 screws (16) from top of air piston. Remove valve disk (8) and spacers (11). Remove washer from valve disk. Inspect all parts for damage. See FIG. 12.




**FIG. 12**

2. Remove set screw (18) and remove air piston head (5). See FIG. 11.



**FIG. 11**

4. Unscrew piston cap (17) and separate from piston (21) to expose dowel pin (19). See FIG. 13.



**FIG. 13**

- Remove dowel pin (19) and take piston cap (17) off transfer shaft (20). Remove o-ring (13\*) from piston cap. Inspect all parts for damage. See FIG. 14.




FIG. 14

- Slide air piston (21) out the top of the air motor base (23). Remove o-ring (3\*) from air motor base. Inspect all parts, including the spring (22) in the air motor base, for damage. See FIG. 15.





FIG. 15

## Pump Lower Repair

- Use a strap wrench at the point indicated in FIG. 16, and a wrench on the flats of the foot valve (45) to remove the foot valve from the suction tube (44). Remove snap ring (47), retaining clip (46), ball (71), and o-ring (38\*) from foot valve (45). Inspect all parts for damage. See FIG. 16.

 When removing the suction tube, be very careful not to bend, dent, or damage it.




FIG. 16

- Use a strap wrench at the point indicated in FIG. 17, remove suction tube (44) from pump body (34). Inspect o-ring (38) on pump body and suction tube for damage. See FIG. 17.




FIG. 17

3. Pull transfer shaft (20) out the bottom of pump body (34). See FIG. 18.




FIG. 18

4. Remove spring pin (56). Remove piston valve (43). Unscrew piston valve (43) from piston housing (53). Remove wear ring (41\*), u-cup (40\*) and ball (42). Inspect all parts for damage. See FIG. 19.




FIG. 19

5. Remove spring pin (55) and slide upper fluid piston (54) down and off the transfer shaft (20). See FIG. 20.




FIG. 20

- Remove set screw (37) from collar (36). Remove collar from piston housing (54). Remove u-cup (35\*). Remove o-ring (57) from ID of piston housing. Inspect all parts for damage. See FIG. 21.




FIG. 21

- Remove hex nut (27) from mounting flange (26). Remove female gland (30\*), 2 PTFE packings (29\*), male gland (28\*) and wiper (31\*). Inspect all parts for damage. See FIG. 23.




FIG. 23

- Remove mounting flange (26) from pump body (34). Remove o-ring (32\*) and PTFE gasket (33\*) from pump body (34). Inspect all parts for damage. See FIG. 22.




FIG. 22


## Reassembly

To reassemble the pump lower and air motor, reverse the steps on the preceding pages. Follow the torque requirements listed in the **Parts** drawing on page 16.


# Troubleshooting

| Problem                                                     | Cause                                       | Solution                                                     |
|-------------------------------------------------------------|---------------------------------------------|--------------------------------------------------------------|
| The pump fails to operate                                   | Dirty or worn air motor.                    | Clean, service                                               |
|                                                             | Inadequate air supply or restricted lines.  | Clean lines or increase the air supply (see Technical Data). |
|                                                             | Closed or clogged air valves.               | Open or clear the valves.                                    |
|                                                             | Clogged fluid hose or valve.                | Clear the hose or valves                                     |
|                                                             | Worn or damaged valves or seals.            | Service the valves or seals.                                 |
| The pump operates, but the output is low on both strokes.   | Clogged fluid hose or valve.                | Clear the hose or valves.                                    |
|                                                             | Exhausted fluid supply.                     | Refill the fluid supply and reprime the pump.                |
|                                                             | Worn or damaged valves or seals.            | Service the valves or seals.                                 |
| The pump operates, but the output is low on the downstroke. | Held open or worn intake valve.             | Clear or service the valve.                                  |
|                                                             | Worn or damaged valves or seals.            | Service the valves or seals.                                 |
| The pump operates, but the output is low on the upstroke.   | Held open or worn piston valve.             | Clear or service the valve.                                  |
|                                                             | Worn or damaged valves or seals.            | Service the valves or seals.                                 |
| Erratic or accelerated operation.                           | Exhausted fluid supply.                     | Refill the fluid supply and reprime the pump.                |
|                                                             | Broken air motor compression spring.        | Replace the spring.                                          |
| Pump slowly moves after fluid shutoff in downstroke.        | Clogged or dirty intake valve check ball.   | Clean ball and seat.                                         |
|                                                             | Worn or damaged valves or seats.            | Install repair kit.                                          |
| Pump slowly moves after fluid shutoff in upstroke.          | Clogged or dirty lower piston ball or seat. | Clean ball and seat.                                         |
|                                                             | Worn or damaged valves or seats.            | Install repair kit.                                          |

# Parts



- 1 Lubricate all o-rings and seals before and after assembly
- 2 Torque to 45-55 ft-lbs (61-74.5 N•m)
- 3 Torque to 30-40 ft-lbs (40.6-54.2 N•m)
- 4 Torque to 15-20 ft-lbs (20.3-27.1 N•m)
- 5 Torque to 10-12 ft-lbs (13.5-16.3 N•m)
- 6 Torque to 110-120 ft-lbs (149.1-162.7 N•m)
- 7 Torque to 20-30 ft-lbs (27.1-40.7 N•m)
- 8 Torque to 50-60 ft-lbs (67.8-81.3 N•m)
- 9 Tighten 1/8 to 1/4 turn past finger-tight



ti9890

ti9973




Parts

| Ref | Part   | Description                                          | Qty | Ref                                                             | Part   | Description                                       | Qty |
|-----|--------|------------------------------------------------------|-----|-----------------------------------------------------------------|--------|---------------------------------------------------|-----|
| 1   | 15J536 | CAP, air cylinder                                    | 1   | 51e                                                             | 15B924 | CLAMP, hopper                                     | 1   |
| 2   | 157630 | SPRING, tapered                                      | 1   | 51f                                                             | 15B925 | HANDLE, hopper clamp                              | 1   |
| 3*  |        | PACKING, square                                      | 2   | 51g                                                             | 15B926 | PIN, pivot, hopper clamp                          | 1   |
| 4   | 15J537 | CYLINDER, air motor                                  | 1   | 52†                                                             | 114558 | COUPLER, air line                                 | 1   |
| 5   | 15J538 | HEAD, air piston                                     | 1   | 53                                                              | 15J570 | HOUSING, piston                                   | 1   |
| 6*  |        | GASKET, upper                                        | 1   | 54                                                              | 15J571 | PISTON, upper                                     | 1   |
| 7   | 15J540 | GUIDE, valve                                         | 1   | 55*                                                             |        | PIN, straight, 3/16 x 3/4                         | 1   |
| 8   | 15J541 | DISK, valve                                          | 1   | 56*                                                             |        | PIN, straight, 3/16 x 1 1/4                       | 1   |
| 9   | 15J542 | CAP, valve guide                                     | 1   | 57*                                                             |        | O-RING                                            | 1   |
| 10* |        | GASKET, lower                                        | 3   | 60                                                              | 120348 | SCREW, cap, socket head<br>1/4-20 x 1 in. (25 mm) | 3   |
| 11  | 15J544 | SPACER, disk                                         | 3   | 69†                                                             | 15H197 | TOOL, spanner wrench                              | 2   |
| 13* |        | O-RING                                               | 1   | 70†                                                             | 15K008 | LABEL, material identification.                   | 1   |
| 14  | 15J546 | DISK, air piston                                     | 1   | 71                                                              | 107167 | BALL, intake, sst, 1 in. (25 mm)                  | 1   |
| 15* |        | O-RING                                               | 1   | 72                                                              | 116343 | SCREW, ground                                     | 1   |
| 16  | 188005 | SCREW, cap, socket head,<br>10-32 x 1 3/8 in. (35mm) | 3   | * Parts included in repair kit 258003 (not sold separately).    |        |                                                   |     |
| 17  | 15J547 | CAP, air piston                                      | 1   | † Indicates parts not shown, 48, 49, 52, 69, 70 (shipped loose) |        |                                                   |     |
| 18  | 102387 | SCREW, set, socket head,<br>10-32 x 3/8 in. (10 mm)  | 1   |                                                                 |        |                                                   |     |
| 19  | 15J548 | PIN, dowel                                           | 1   |                                                                 |        |                                                   |     |
| 20  | 15J549 | SHAFT, transfer                                      | 1   |                                                                 |        |                                                   |     |
| 21  | 288338 | PISTON, air                                          | 1   |                                                                 |        |                                                   |     |
| 22  | 15J551 | SPRING, compression                                  | 1   |                                                                 |        |                                                   |     |
| 23  | 15J552 | BASE, air motor                                      | 1   |                                                                 |        |                                                   |     |
| 24* |        | O-RING                                               | 1   |                                                                 |        |                                                   |     |
| 25  | 15J553 | ROD, tie                                             | 3   |                                                                 |        |                                                   |     |
| 26  | 15J554 | FLANGE, mounting                                     | 1   |                                                                 |        |                                                   |     |
| 27  | 15J555 | NUT, hex                                             | 1   |                                                                 |        |                                                   |     |
| 28* |        | GLAND, packing, (male)                               | 1   |                                                                 |        |                                                   |     |
| 29* |        | V-PACKING, PTFE                                      | 2   |                                                                 |        |                                                   |     |
| 30* |        | GLAND, packing, (female)                             | 1   |                                                                 |        |                                                   |     |
| 31* |        | WIPER, ROD                                           | 1   |                                                                 |        |                                                   |     |
| 32* |        | O-RING, PTFE, encapsulated                           | 1   |                                                                 |        |                                                   |     |
| 33* |        | GASKET, PTFE                                         | 1   |                                                                 |        |                                                   |     |
| 34  | 288339 | BODY, pump, 2:1                                      | 1   |                                                                 |        |                                                   |     |
| 35* |        | PACKING, piston cup                                  | 1   |                                                                 |        |                                                   |     |
| 36  | 15J563 | COLLAR, retaining                                    | 1   |                                                                 |        |                                                   |     |
| 37  | 101194 | SCREW, set, socket head,<br>10-32 x .25 in. (6 mm)   | 1   |                                                                 |        |                                                   |     |
| 38* |        | O-RING                                               | 2   |                                                                 |        |                                                   |     |
| 39  | 15J564 | CYLINDER, pressure pump                              | 1   |                                                                 |        |                                                   |     |
| 40* |        | PACKING, u-cup, PTFE                                 | 1   |                                                                 |        |                                                   |     |
| 41* |        | RING, wear                                           | 1   |                                                                 |        |                                                   |     |
| 42  | 103462 | BALL, outlet, sst, 3/4 in. (19 mm)                   | 1   |                                                                 |        |                                                   |     |
| 43  | 15J567 | VALVE, piston                                        | 1   |                                                                 |        |                                                   |     |
| 44  | 15J568 | TUBE, suction                                        | 1   |                                                                 |        |                                                   |     |
| 45  | 15J569 | VALVE                                                | 1   |                                                                 |        |                                                   |     |
| 46  | 120734 | RING, retaining, internal                            | 1   |                                                                 |        |                                                   |     |
| 47  | 120735 | RING, snap, e series                                 | 1   |                                                                 |        |                                                   |     |
| 48† | 206264 | VALVE, needle                                        | 1   |                                                                 |        |                                                   |     |
| 49† | 169969 | FITTING, air line                                    | 1   |                                                                 |        |                                                   |     |
| 50* |        | O-RING                                               | 1   |                                                                 |        |                                                   |     |
| 51  | 253146 | ADAPTER, bung<br>(includes 51a-51g)                  | 1   |                                                                 |        |                                                   |     |
| 51a | 120998 | O-RING, fluoroelastomer                              | 1   |                                                                 |        |                                                   |     |
| 51b | 15H196 | ADAPTER                                              | 1   |                                                                 |        |                                                   |     |
| 51c | 110420 | SCREW, cap socket head                               | 1   |                                                                 |        |                                                   |     |
| 51d | 116876 | WASHER, flat                                         | 1   |                                                                 |        |                                                   |     |

# Technical Data

|                                                                   |                                                                        |
|-------------------------------------------------------------------|------------------------------------------------------------------------|
| Pressure Ratio . . . . .                                          | 2.25:1                                                                 |
| Max fluid working pressure . . . . .                              | 405 psi (2.8 MPa, 28 bar)                                              |
| Maximum Air inlet pressure . . . . .                              | 180 psi (1.2 MPa, 12 bar)                                              |
| Max Output Flow (continuous) . . . . .                            | 5.0 GPM (20 lpm)                                                       |
| Max Output Flow (intermittent) . . . . .                          | 7.5 GPM (28 lpm)                                                       |
| Pump cycles per 1 gallon (3.8 liters) . . . . .                   | 15.9                                                                   |
| Maximum recommended pump speed for continuous operation . . . . . | 100 cycles per min (150 cycles per min intermittent)                   |
| Gallons (liters) per pump cycle . . . . .                         | 0.063 (.24)                                                            |
| Air consumption . . . . .                                         | See performance chart                                                  |
| Maximum Ambient temperature . . . . .                             | 120° F (50° C)                                                         |
| Maximum Fluid Temperature . . . . .                               | 190° F (88° C)                                                         |
| Maximum operating temperature of fluid pump . . . . .             | 480° F (248° C) for non-hazardous location applications only (runaway) |
| Maximum operating temperature of air motor . . . . .              | 280° F (138° C) for non-hazardous location applications only (runaway) |
| Wetted parts . . . . .                                            | Stainless Steel, PTFE                                                  |
| Air Inlet Port . . . . .                                          | 1/4 npt(f)                                                             |
| Fluid Outlet Port . . . . .                                       | 3/4 npt(f)                                                             |
| Weight . . . . .                                                  | 21.0 lb (9.5 kg)                                                       |
| Sound Pressure . . . . .                                          | 88.7 dB(A) at 80 psi (.55 MPa, 5.5 bar)                                |
| Sound Power, per ISO 9614-2 . . . . .                             | 96.8 dB(A) at 80 psi (.55 MPa, 5.5 bar)                                |

# Dimensions



# Performance Chart

## Calculate Fluid Outlet Pressure (black curves)

To calculate fluid outlet pressure (MPa/bar/psi) at a specific fluid flow (lpm/gpm) and operating air pressure (MPa/bar/psi), use the following instructions and pump data chart.

1. Locate desired flow along bottom of chart.
2. Follow vertical line up to intersection with selected fluid outlet pressure curve (black). Follow left to scale to read fluid outlet pressure.


## Calculate Pump Air Consumption (gray curves)

To calculate pump air consumption ( $m^3/min$  or scfm) at a specific fluid flow (lpm/gpm) and air pressure (MPa/bar/psi), use the following instructions and pump data chart.

1. Locate desired flow along bottom of chart.
2. Follow vertical line up to intersection with selected air consumption curve (gray). Follow right to scale to read air consumption.

### Key: Air Pressure

- A 180 psi (1.2 MPa, 12.4 bar)
- B 100 psi (0.7 MPa, 7 bar)
- C 70 psi (0.5 MPa, 7.8 bar)
- D 40 psi (0.3 MPa, 2.8 bar)



# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

**TO PLACE AN ORDER**, contact your Graco distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

This manual contains English. MM 311882

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441**

www.graco.com

04/2007